



# COBRA FACESHIELD INSTRUCTIONS

EN 166:2001



BSI Product Services, Maylands Avenue,  
Hemel Hempstead, Hertfordshire,  
HP2 4SQ, United Kingdom



## STORAGE:

When not in use or during transportation, the faceshield should be stored in a container such that it is out of direct sunlight, not in contact with solvents and can not be damaged by physical contact with hard surfaces/items. Do not store outside the temperature range of -20°C or +50°C or with humidity above 90%RH.

## UNPACKING INSTRUCTIONS:

Carefully remove the faceshield from packaging, taking particular note of instructions printed on or included with the faceshield. Remove the protective film on the visor. Do not use if items appear damaged or missing.

## ADJUSTMENT:

The head height and size can be adjusted as follows:

1. Slide left half of crown strap through loops on the right half to obtain correct height, engage retaining pin in correct hole
2. Place faceshield on head and check height setting. Ensure headband is not too low on brow. If necessary repeat step 1 until correct height adjustment is achieved.
3. Adjust elastic at the rear of the harness to ensure a firm and comfortable fit around the head.

## USE:

No protection is given unless the visor is correctly fitted and in the lowered position. Susceptible individuals may experience an allergic reaction to those parts of the faceshield that come into contact with the wearer's skin. If this is the case, leave the hazard area, remove the faceshield and seek doctor's advice. None of the materials used in the manufacture of the faceshield are known to adversely affect user hygiene or health. The visor can be raised or lowered as required by loosening the two side pivot nuts. Below is a guide to the marking that appears on the product.

**WARNING:** This eye protector is suitable for use to the lowest marking on the browguard or the visor

## MARKING

## PROTECTION



|        |                                                |
|--------|------------------------------------------------|
|        | JSP Ltd. Trademark                             |
| EN 166 | EN 166:2001 British & European Standard Number |
| B      | Medium energy high speed particle impact       |
| F      | Low energy high speed particle impact          |
| S      | Increased robustness                           |
| 3      | Liquid Splash                                  |
| 9      | Molten Metal                                   |
| 1      | Optical quality (1 = high, 3 = low)            |

## Cleaning / Disinfection:

To maintain the faceshield in the best possible condition do not use abrasive materials to clean them. Rinse in mild detergent in tap water and dry with a soft cloth

## VISOR REPLACEMENT

Scratched or damaged visors should be replaced. Replacement visors are available for all faceshields. Under normal circumstances the faceshield and visor should offer adequate protection for 2-3 years.



JSP Ltd, Worsham Mill, Minster Lovell, Oxford OX29 0TA

www.jsp.co.uk

Tel: 01993 824000 Fax: 01993 824411

Technical Helpline: 01993 824000