

CODE	Description	Ring No	Make	Size	Model
MV-AR-861001	Maxvac Adaptor Ring AEG- 5"	31.0	AEG	5 inch/125mm	WS-6
MV-AR-861002	Maxvac Adaptor Ring AEG- 5"	32.0	AEG	5 inch/125mm	WS 10
MV-AR-861002	Maxvac Adaptor Ring AEG- 5"	32.0	AEG	5 inch/125mm	WS 11
MV-AR-861002	Maxvac Adaptor Ring AEG- 5"	32.0	AEG	5 inch/125mm	WS 12
MV-AR-861002	Maxvac Adaptor Ring AEG- 5"	32.0	AEG	5 inch/125mm	WS 9
MV-AR-861003	Maxvac Adaptor Ring AEG- 5"	33.0	AEG	5 inch/125mm	BEW-18
MV-AR-862001	Maxvac Adaptor Ring AEG- 9" A/B p/stk**	34.0	AEG	9 inch/230mm	WS-22
MV-AR-862002	Maxvac Adaptor Ring AEG- 9" C/D p/stk**	35.0	AEG	9 inch/230mm	WS-24
MV-AR-861008	Maxvac Adaptor Ring AIMSAC -125 A/B **	12.0	AIMSAK	5 inch/125mm	BL18G70 / BL22G90 Accu
MV-AR-861300	Maxvac Adaptor Ring BER- 5" (A/B) **	39.0	Berner	5 inch/125mm	125 mm modellen
MV-AR-862300	Maxvac Adaptor Ring BER - 9" (A/B) **	40.0	Berner	9 inch/230mm	230 mm modellen
MV-AR-861030	Maxvac Adaptor Ring Grinder Shroud - Bosch A/B (4)	4.0	Bosch	5 inch/125mm	
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	G/P WS 13-125 CE
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 1000
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 10-125 (geen letter)
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 10-125 CE
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 10-125 Z
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 11-125 CI
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 11-125 CIE
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 11-125 CIH
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 11-125CI
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 12 CI
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 1400
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 14-125 CI
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 14-125 CIE
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 15-125 CIEH
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 15-125 CIH
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 15-125 CITH
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 17 125CF
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 19-125 CIE
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS 9-115P
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Bosch	5 inch/125mm	GWS17 125CF

MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS 660 / GWS700
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS750
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS880
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS6-115
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS9-115S
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	18V-10SC
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	850 W. model
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS 7 - 115
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Bosch	5 inch/125mm	GWS 8-125
MV-AR-861022	Maxvac Adaptor Ring BO - 5"	3.1 + SPR04	Bosch	5 inch/125mm	GWS 18-125V-LI (batt)
MV-AR-861032	Maxvac Adaptor Ring for AGS125 Ring nr 5	5.0	Bosch	5 inch/125mm	PWS700
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 12-230HV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 2000-230
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 20-230 H
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 21-230 H
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 21-230 HV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 21-230 HV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 21-230 JH
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 21-230 JHV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 22-230 H --> 2008
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 B
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 BV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 JB
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 JBV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 JBX
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 JH t/m 2013
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 24-230 JVC
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 B
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 BV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 H
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 JB
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 JBV
MV-AR-862030	Maxvac Adaptor Ring BO - 9" (A/B)	20.0	Bosch	9 inch/230mm	GWS 26-230 JH

MV-AR-862030	Maxvac Adaptor Ring - Bosch A/B (20)	20.0	Bosch		
MV-AR-862032	Maxvac Adaptor Ring BO - 9" C/D p/stk (vs03.14)	21.0	Bosch	9 inch/230mm	GWS 22-230 H 2008 -->
MV-AR-862032	Maxvac Adaptor Ring BO - 9" C/D p/stk (vs03.14)	21.0	Bosch	9 inch/230mm	GWS 24-180 JBV
MV-AR-862032	Maxvac Adaptor Ring BO - 9" C/D p/stk (vs03.14)	21.0	Bosch	9 inch/230mm	GWS 24-230 LVI
MV-AR-862032	Maxvac Adaptor Ring BO - 9" C/D p/stk (vs03.14)	21.0	Bosch	9 inch/230mm	va/ab/from1-8-2014
MV-AR-862032	Maxvac Adaptor Ring - Bosch C/D (21)	21.0	Bosch		
MV-AR-862033	Maxvac Adaptor Ring BO- 9" E/F p/stk **	30.0	Bosch	9 inch/230mm	GWS 26-230 LVI
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 2000-18J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 20-180 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 20-230 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 23-180 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 23-230 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 25-180 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 25-230 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS 25-230 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS-180 J
MV-AR-862034	Maxvac Adaptor Ring BO- 9" G/H p/stk **	30.1	Bosch	9 inch/230mm	GWS-230 J
MV-AR-862034	Maxvac Adaptor Ring - Bosch G/H (30.1)	30.1	Bosch		
MV-AR-862035	Maxvac Adaptor Ring BO- 9" I/J p/stk **	30.2	Bosch	9 inch/230mm	GWS 22-230 JH tot 2014
MV-AR-862035	Maxvac Adaptor Ring BO- 9" I/J p/stk **	30.2	Bosch	9 inch/230mm	GWS 22-230 LVI
MV-AR-862035	Maxvac Adaptor Ring - Bosch I/J (30.2)	30.2	Bosch		
MV-AR-862036	Maxvac Adaptor Ring BO- 9" K/L p/stk **	30.3	Bosch	9 inch/230mm	GWS 20-230 H
MV-AR-862036	Maxvac Adaptor Ring BO- 9" K/L p/stk **	30.3	Bosch	9 inch/230mm	GWS 24-230 JH va 2014
MV-AR-862036	Maxvac Adaptor Ring - Bosch K/L (30.3)	30.3	Bosch		
MV-AR-862037	Maxvac Adaptor Ring BO-230 M/N + High flange + 4 mm ring p/p ****	30.4	Bosch	9 inch/230mm	GWS 22-230 JH va 2014
MV-AR-861020	Maxvac Adaptor Ring DW - 5" (A/B)	2.0	Dewalt	5 inch/125mm	DW831
MV-AR-861021	Maxvac Adaptor Ring DW - 5" (C/D) **	3.0	Dewalt	5 inch/125mm	Accu DCG412M3
MV-AR-861021	Maxvac Adaptor Ring DW - 5" (C/D) ** May need SPR03 if using mortar raking blade	3.0	Dewalt	5 inch/125mm	DWE4206 / DWE4206LX
MV-AR-861021	Maxvac Adaptor Ring DW - 5" (C/D) **	3.0	Dewalt	5 inch/125mm	D28139
MV-AR-861023	Maxvac Adaptor Ring DW - 5" (C/D) + SPR5.5	3.2	Dewalt	5 inch/125mm	DCG414 / 418 FLEXVOLT
MV-AR-861021	Maxvac Adaptor Ring DW - 5" (C/D) **	3.0	Dewalt	5 inch/125mm	Hitachi accu G18 DBL
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28065-D28066

MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28113 / D28113-3
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28114-D28116
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28131
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28132-133-134
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28138
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28402
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14) + SPR5.5	3.1	Dewalt	5 inch/125mm	DCG412
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DW821
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DW821 QS
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DW824
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DW831
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE4056
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	6 inch/125mm	4016
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE818
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	D28 128-08
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE 4050 / 4051
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE4202/4203/4204/4205/4207
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE4213/4214/4215/4216/4217
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14)	3.1	Dewalt	5 inch/125mm	DWE46101 / 46102
MV-AR-861023	Maxvac Adaptor Ring DW - 5" (G/H)	3.2	Dewalt	5 inch/125mm	DC(G)413-DC(G)415 accu
MV-AR-861023	Maxvac Adaptor Ring DW - 5" (G/H)	3.2	Dewalt	5 inch/125mm	DCG405
MV-AR-861023	Maxvac Adaptor Ring DW - 5" (G/H)	3.2	Dewalt	5 inch/125mm	DCG405-FN
MV-AR-862020	Maxvac Adaptor Ring DW - 9" (A/B)	19.0	Dewalt	9 inch/230mm	D28400-QS
MV-AR-862020	Maxvac Adaptor Ring DW - 9" (A/B)	19.0	Dewalt	9 inch/230mm	D28422-QS
MV-AR-862020	Maxvac Adaptor Ring DW - 9" (A/B)	19.0	Dewalt	9 inch/230mm	D28423-QS
MV-AR-862020	Maxvac Adaptor Ring DW - 9" (A/B)	19.0	Dewalt	9 inch/230mm	D28432C-QS
MV-AR-862020	Maxvac Adaptor Ring - Dewalt A/B (19)	19.0	Dewalt	9 inch/230mm	
MV-AR-861022	Maxvac Adaptor Ring DW - 5" (E/F) (vs9.14) + SPR5.5	3.1	Dewalt	5 inch/125mm	DCG405FN-XJ
MV-AR-861110	Maxvac Adaptor Ring EB - 5" (A/B) **	15.0	Eibenstock	5 inch/125mm	All 125 mm Models
MV-AR-861110	Maxvac Adaptor Ring Grinder Shroud - Eibenstock A/B (15)	15.0	Eibenstock	5 inch/125mm	
MV-AR-862110	Maxvac Adaptor Ring EB - 9" (A/B) **	28.0	Eibenstock	9 inch/230mm	All 230 mm Models

MV-AR-861042	Maxvac Adaptor Ring 115mm 6.1	6.1	Erbauer	115mm	EAG900
MV-AR-862042	Maxvac Adaptor Ring 22.1 plus SPR8.0	22.1	Erbauer	230mm	EAG2200
MV-AR-861040	Maxvac Adaptor Ring 6	6.0	Erbauer/Einhell	115	TEAG18
MV-AR-861070	Maxvac Adaptor Ring FE - 5" (A/B)	11.0	Fein	5 inch/125mm	WSB13-125
MV-AR-861070	Maxvac Adaptor Ring FE - 5" (A/B)	11.0	Fein	5 inch/125mm	WSG14-125
MV-AR-861070	Maxvac Adaptor Ring FE - 5" (A/B)	11.0	Fein	5 inch/125mm	WSS12-125
MV-AR-861070	Maxvac Adaptor Ring FE - 5" (A/B)	11.0	Fein	5 inch/125mm	WSS14-125
MV-AR-861071	Maxvac Adaptor Ring FE - 5" (C/D)	11.1	Fein	5 inch/125mm	WSG11-125
MV-AR-861200	Maxvac Adaptor Ring PRO - 5" (A) ***	42.0	Festool	5 inch/125mm	AG 125 - xx xx
MV-AR-861200	Maxvac Adaptor Ring Grinder Shroud - Festool, , Part A (42)	42.0	Festool	5 inch/125mm	
MV-AR-861010	Maxvac Adaptor Ring FL/KG- 5" A/B (Flex)	1.0	Flex	5 inch/125mm	Standaard
MV-AR-861011	Maxvac Adaptor Ring Grinder Shroud - Flex C/D (1.1)	1.1	Flex	2 inch	
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L1506VR
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L1510FRA
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L3309FRG
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L3406VRG
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L3410FRG
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	L3410VR
MV-AR-861011	Maxvac Adaptor Ring FL/KG- 5" C/D p/stk **	1.1	Flex	5 inch/125mm	LE14-7 125 inox
MV-AR-861012	Maxvac Adaptor Ring Grinder Shroud - Flex E/F (1.2)	1.2	Flex	3 inch	
MV-AR-861012	Maxvac Adaptor Ring FL- 5" E/F p/stk **	1.2	Flex	5 inch/125mm	L1000 - L1010
MV-AR-861014	Maxvac Adaptor Ring FL- 5" G p/stk ***	1.4	Flex	5 inch/125mm	L800 / L3709
MV-AR-861015	Maxvac Adaptor Ring FL- 5" H/I p/stk **	1.5	Flex	5 inch/125mm	L1001
MV-AR-861015	Maxvac Adaptor Ring FL- 5" H/I p/stk **	1.5	Flex	5 inch/125mm	L10-10
MV-AR-861015	Maxvac Adaptor Ring FL- 5" H/I p/stk **	1.5	Flex	5 inch/125mm	L810
MV-AR-861016	Maxvac Adaptor Ring FL- 5" J/K p/stk **	1.6	Flex	5 inch/125mm	L08-11
MV-AR-861016	Maxvac Adaptor Ring FL- 5" J/K p/stk **	1.6	Flex	5 inch/125mm	L10-11
MV-AR-861016	Maxvac Adaptor Ring FL- 5" J/K p/stk **	1.6	Flex	5 inch/125mm	L14-11
MV-AR-861016	Maxvac Adaptor Ring FL- 5" J/K p/stk **	1.6	Flex	5 inch/125mm	LE09-11
MV-AR-861016	Maxvac Adaptor Ring FL- 5" J/K p/stk **	1.6	Flex	5 inch/125mm	LE14-11
MV-AR-861017	Maxvac Adaptor Ring FL- 5" L/M p/stk **	1.7	Flex	5 inch/125mm	L15-10 (alleen 125 mm )
MV-AR-861018	Maxvac Adaptor Ring FL- 5" N/O p/stk **	1.8	Flex	5 inch/125mm	LB (E) 17-11 125
MV-AR-862010	Maxvac Adaptor Ring FL/KG - 9" (A/B) (Flex) **	18.0	Flex	9 inch/230mm	230 mm model. tm 2013

MV-AR-862010	Maxvac Adaptor Ring - Flex A/B (18)	18.0	Flex	9 inch/230mm	
MV-AR-862012	Maxvac Adaptor Ring Flex - 9" + Ring (C/D) (Flex) ***	18.1	Flex	9 inch/230mm	L21-0 - L21-6
MV-AR-862012	Maxvac Adaptor Ring Flex - 9" + Ring (C/D) (Flex) ***	18.1	Flex	9 inch/230mm	L2406
MV-AR-862012	Maxvac Adaptor Ring Flex - 9" + Ring (C/D) (Flex) ***	18.1	Flex	9 inch/230mm	L26-6
MV-AR-862012	Maxvac Adaptor Ring - Flex C/D (18.1)	18.1	Flex	9 inch/230mm	
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G12SA2
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G12SA3
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13-JQ
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13SB2-125
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13SB3
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13SC2
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13SE2
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13VA
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13VE
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13YC-125
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G13YF
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G15VA
MV-AR-861060	Maxvac Adaptor Ring HI - 5" (A/B)	9.0	HiKOKI	5 inch/125mm	G15YF
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	accu G18 DSL
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G12SS2
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G12STX
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G13SD
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G13SR3
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G13SR4
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G13SS
MV-AR-861061	Maxvac Adaptor Ring HI - 5" (C/D) HiKOKI 800 W **	10.0	HiKOKI	5 inch/125mm	G13STA
MV-AR-861062	Maxvac Adaptor Ring HI - 5" HI-125 E/F p/stk HiKOKI Accu **	10.1	HiKOKI	5 inch/125mm	18 volt accu modellen
MV-AR-861063	Maxvac Adaptor Ring HI - 5" (G/H) HiKOKI 800 W ** (vs4.17)	10.2	HiKOKI	5 inch/125mm	G13SR4(S)
MV-AR-862060	Maxvac Adaptor Ring HI - 9" (A/B)	25.0	HiKOKI	9 inch/230mm	All 230 mm Models
MV-AR-862061	Maxvac Adaptor Ring HI - 9" (C/D)**	25.1	HiKOKI	9 inch/230mm	G 23 (4) (U) BY
MV-AR-862061	Maxvac Adaptor Ring HI - 9" (C/D)**	25.1	HiKOKI	9 inch/230mm	G 23 SS
MV-AR-862061	Maxvac Adaptor Ring HI - 9" (C/D)**	25.1	HiKOKI	9 inch/230mm	G 23 ST
MV-AR-861081	Maxvac Adaptor Ring HIL- 5" A/B p/stk**	36.0	Hilti	5 inch/125mm	G 12SE 2

MV-AR-861081	Maxvac Adaptor Ring HIL- 5" A/B p/stk**	36.0	Hilti	5 inch/125mm	DSG 125 S
MV-AR-862082	Maxvac Adaptor Ring HIL- 9" A/B p/stk**	37.0	Hilti	9 inch/230mm	DCG 230
MV-AR-861062	Maxvac Adaptor Ring Grinder Shroud	25.1	HiKOKI	9 inch/230mm	G23ST
MV-AR-861050	Maxvac Adaptor Ring KE - 5" (A/B) **	8.0	Keyang	5 inch/125mm	DG125-15SV
MV-AR-861090	Maxvac Adaptor Ring KE - 5" (A/B) **	13.0	Keyang	5 inch/125mm	WSS14-126
MV-AR-862090	Maxvac Adaptor Ring KE - 9" (A/B) **	26.0	Keyang	9 inch/230mm	All 230 mm Models
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA456
MV-AR-861040	Maxvac Adaptor Ring MA - 5"	6.0	Makita	5 inch/125mm	GA013G
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA504
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA513Z
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA517Z
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA467
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA454
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA463
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	GA5040C
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA452
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA4540C
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA5021C
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9553 NB / 9555 NB
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9557NB
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9558 HN
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9527NB
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9558NB
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	9558PB
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA 452
MV-AR-861040	Maxvac Adaptor Ring MA - 5" (A/B) (vs8.14)	6.0	Makita	5 inch/125mm	DGA 504 - 505
MV-AR-861042	Maxvac Adaptor Ring MA - 5" E/F	6.1	Makita	5 inch/125mm	GA-5030
MV-AR- 861042	Maxvac Adaptor Ring Grinder Shroud - Makita E/F (6.1)	6.1	Makita	5 inch/125mm	GA4530R
MV-AR- 861042	Maxvac Adaptor Ring Grinder Shroud - Makita E/F (6.1)	6.1	Makita	5 inch/125mm	GA5030R
MV-AR-862040	MUST SEND THIS IN FOR FITTING SERVICE ONLY	6.1	Makita	5 inch/125mm	GA022G
MV-AR-861043	Maxvac Adaptor Ring MA - 5" G/H	6.2	Makita	5 inch/125mm	GA 5021
MV-AR-861022	Maxvac Adaptor Ring 3.1	3.1	Makita	5 inch/125mm	M9502R
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9562CR

MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9562CVH
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9562CVR
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9565CV
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9015B
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	DGA900Z
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9565CVR
MV-AR-861041	Maxvac Adaptor Ring MA - 5" (C/D)	7.0	Makita	5 inch/125mm	9565H
MV-AR-861044	MAKITA X LOCK 5" RING 6.3	6.3	Makita	5 inch/125mm	XLOCK
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7020S
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7020SFK
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7020SFYK
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7030SF01
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7030SFY
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7040SF01
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 7040SFY
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9010C
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9020SFYK
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9030S
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9030SF01
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9030SFY
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9040S
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9040SF01
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9040SFY
MV-AR-862040	Maxvac Adaptor Ring MA - 9" (A/B)	22.0	Makita	9 inch/230mm	GA 9047 t/m 9049
MV-AR-862042	Maxvac Adaptor Ring MA - 9" (E/F) + <b>SPR05.5</b>	22.1	Makita	9 inch/230mm	GA9020KD
MV-AR-862042	Maxvac Adaptor Ring MA - 9" (E/F) **	22.1	Makita	9 inch/230mm	G23 UDY
MV-AR-862042	Maxvac Adaptor Ring MA - 9" (E/F) **	22.1	Makita	9 inch/230mm	GA 9020
MV-AR-862042	Maxvac Adaptor Ring MA - 9" (E/F) **	22.1	Makita	9 inch/230mm	GA 9020 R
MV-AR-862042	Maxvac Adaptor Ring MA - 9" (E/F) **	22.1	Makita	9 inch/230mm	GA 9020 S
MV-AR-862041	Maxvac Adaptor Ring MA - 9" (E/F) ** + <b>SPR05.5</b>	23.0	Makita	9 inch/230mm	GA 9050
MV-AR-862041	Maxvac Adaptor Ring MA - 9" (C/D) **	23.0	Makita	9 inch/230mm	GA 9012CF
MV-AR-862043	Maxvac Adaptor Ring MA - 9" (C/D) ** + Flange 5,5 mm	23.1	Makita	9 inch/230mm	DGA900-DGA901 (accu)
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	All 125 mm Models



MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	W8-125 Quick
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	WB11-125Quick
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	WB14-125 Plus
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	WBA11-125Quick
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	WE 9-125 Quick
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Metabo	5 inch/125mm	WE14-125
MV-AR-861050	Maxvac Adaptor Ring Grinder Shroud - Metabo A/B (8)	8.0	Metabo	5 inch/125mm	
MV-AR-862050	Maxvac Adaptor Ring ME - 9" (A/B)	24.0	Metabo	9 inch/230mm	180/230 alle modellen
MV-AR-862050	Maxvac Adaptor Ring ME - 9" (A/B)	24.0	Metabo	9 inch/230mm	EWS modellen
MV-AR-862050	Maxvac Adaptor Ring ME - 9" (A/B)	24.0	Metabo	9 inch/230mm	WX Partner Edition
MV-AR-862050	Maxvac Adaptor Ring ME - 9" (A/B)	24.0	Metabo	9 inch/230mm	WX23-230Quick
MV-AR-862050	Maxvac Adaptor Ring - Metabo A/B (24)	24.0	Metabo	9 inch/230mm	
MV-AR-861100	Maxvac Adaptor Ring MI - 5" (A/B) **	14.0	Milwaukee	5 inch/125mm	125 mm Model. t/m 2014
MV-AR-861100	Maxvac Adaptor Ring MI - 5" (A/B) **	14.0	Milwaukee	5 inch/125mm	AG12-12SX
MV-AR-861101	Maxvac Adaptor Ring MI - 5" (C/D) **	14.1	Milwaukee	5 inch/125mm	AG10 - 125 EK
MV-AR-861101	Maxvac Adaptor Ring MI - 5" (C/D) **	14.1	Milwaukee	5 inch/125mm	M18 115XPDB
MV-AR-861101	Maxvac Adaptor Ring MI - 5" (C/D) **	14.1	Milwaukee	5 inch/125mm	AG11-125
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AG22-180
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AG22-230
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AG22-230E
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AGV22-180E
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AGV22-230
MV-AR-862100	Maxvac Adaptor Ring MI - 9" (A/B) **	27.0	Milwaukee	9 inch/230mm	AGV22-230E
MV-AR-862101	Maxvac Adaptor Ring MI - 9" (C/D) **	29.0	Milwaukee	9 inch/230mm	230 mm Model. t/m 2014
MV-AR-861400	Maxvac Adaptor Ring Wü-4,5" A/B ***	41.0	Milwaukee	5 inch/125mm	28 Volt machine
MV-AR-861400	Maxvac Adaptor Ring Grinder Shroud - Milwaukee A/B (41)	41.0	Milwaukee	5 inch/125mm	
MV-AR-862200	Maxvac Adaptor Ring PRO - 9" (A/B) **	38.0	Protool	9 inch/230mm	AGP 230-4
MV-AR-861200	Maxvac Adaptor Ring PRO - 5" (A) ***	42.0	Protool	5 inch/125mm	AGP 125 - xx xx
MV-AR-861200	Maxvac Adaptor Ring Grinder Shroud - Protool A/B (42)	42.0	Protool	5 inch/125mm	
MV-AR-861230	Maxvac Adaptor Ring SP-125 A/B p/pcs**	52.0	Sparky	5 inch/125mm	Sparky 1050
MV-AR-861232	Maxvac Adaptor Ring SP-125 C/D p/pcs**	54.0	Sparky	5 inch/125mm	Sparky 1050e
MV-AR-862410	Maxvac Adaptor Ring SPT- 9" (A/B) **	46.0	Spit	9 inch/230mm	AGP 230 AV
MV-AR-861206	Maxvac Spacer Ring - 5" 4 mm universal	16.0	Univ.	5 inch/125mm	All 125 mm Models

MV-AR-861210	Maxvac Spacer Ring - 5" 10 mm universal	17.0	Univ.	5 inch/125mm	All 125 mm Models
MV-AR-861206	Maxvac Adaptor Ring Grinder Shroud - Universal, , Part (16)	16.0	Universal	5 inch/125mm	
MV-AR-861210	Maxvac Adaptor Ring Grinder Shroud - Universal, , Part (17)	17.0	Universal	5 inch/125mm	
MV-AR-861030	Maxvac Adaptor Ring Grinder Shroud - Würth A/B (4)	4.0	Würth	5 inch/125mm	
MV-AR-861030	Maxvac Adaptor Ring BO - 5" (A/B)	4.0	Würth	5 inch/125mm	Modellen t/m 2014
MV-AR-861032	Maxvac Adaptor Ring BO - 5" (C/D) Bosch 850 C **	5.0	Würth	5 inch/125mm	18 Volt accu
MV-AR-861032	Maxvac Adaptor Ring Grinder Shroud - Würth C/D (5)	5.0	Würth	5 inch/125mm	
MV-AR-861050	Maxvac Adaptor Ring ME - 5" (A/B)	8.0	Würth	5 inch/125mm	Modellen va 2015
MV-AR-861050	Maxvac Adaptor Ring Grinder Shroud - Würth A/B (8)	8.0	Würth	5 inch/125mm	
MV-AR-862050	Maxvac Adaptor Ring - Würth A/B (24)	24.0	Würth	9 inch/230mm	
MV-AR-861400	Maxvac Adaptor Ring Wü-4,5" A/B ***	41.0	Würth	5 inch/125mm	EWS 28 Volt
MV-AR-861400	Maxvac Adaptor Ring Grinder Shroud - Würth A/B (41)	41.0	Würth	5 inch/125mm	
MV-AR-861220		50.0		5 inch/125mm	EY46A2 accu
	ALL MAKITA 5INCH/125MM RINGS NEED SPRO4 TO BE ADDED				