

SPARE PARTS LIST

MODEL NO. 9031

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	152490-4	GRIP 36 COMPLETE	1	
003	286241-4	CAP 30 9031	1	
004	951116-3	*TENSION PIN 4-20 DIN1481 10PK	1	
005	265999-8	*PT SCREW 4X25 10PK	3	
006	342152-4	FLAT SHOE 9030/9031	1	
007	266035-3	*CT SCREW M5X12 9031 10PK	1	
008	231056-4	*COMPRESSION SPRING 13 5PK	1	
009	253052-2	*NARROW THIN WASHER 12 10PK	1	
010	252605-4	NUT M16 9030/9031	1	
011	159748-2	GEAR HOUSING COMPLETE 9031	1	
012	211023-5	BALL BEARING 607LB 9540/9541/9	1	
013	226435-9	HELICAL GEAR 35 9031	1	
014	258009-8	SPRING PIN 9031	1	
015	211331-4	'BALL BEARING 6904DDW 9031	1	
016	285830-2	'BEARING RETAINER 44 9031	1	
017	266058-1	*COUNTERSUNK SCREW M4X12 10PK	2	
018	222129-4	PULLEY 33-64 9031	1	
019	794115-0	ABRASIVE BELT 30X533 AA100	1	
020	415624-3	PULLEY LINER 9031	1	
021	941101-4	*FLAT WASHER 5 DIN125-B 10PK	1	
022	266067-0	*CAP HD SCREW M5X20 L.THR 5PK	1	
023	265995-6	*PT SCREW 4X18 10PK LF1000	3	
024	415635-8	HANDLE COVER 9031/9032	1	
025	651263-7	SWITCH SGEL206C 9031/9032	1	
026	645200-1	NOISE SUPPRESSOR LS0714/JR3060LC1230/RP1100C/3705/HM1810/307115V		
027	631676-8	CONTROLLER 110V 9031/9032	1	115V
028	265995-6	*PT SCREW 4X18 10PK LF1000	2	
029	687063-9	STRAIN RELIEF HR2400/3707/37082414NB/9920/RP1100C	1	
030	663926-3	POWER SUPPLY CORD 1.0-2-2.5	1	115V
031	682502-4	CORD GUARD 8-85 3707/N1923B	1	
032	951116-3	*TENSION PIN 4-20 DIN1481 10PK	1	
033	322746-1	TOP PULLEY SHAFT 9031	1	
034	222130-9	PULLEY 30-25 9031	1	
035	210015-1	BALL BEARING 688DDW 9031	1	
036	331450-1	SLEEVE 12 9031	1	
037	210015-1	BALL BEARING 688DDW 9031	1	
038	154417-0	ANGLE STAY COMPLETE 9031	1	
039	165110-1	ARM COMPLETE 9031	1	
040	253904-7	*WAVE WASHER 12 9031 5PK	2	
041	252138-9	HEX NUT M6-17 9031	1	
042	857678-8	NAME PLATE 9031	1	
043	191940-4	CARBON BRUSH CB-411	1	
044	643550-8	BRUSH HOLDER CAP CB-9-14-17/N1	2	
045	159747-4	MOTOR HOUSING COMPLETE 9031	1	
046	599327-8	FIELD ASSY 110V 9031	1	115V
047	266052-3	*PT SCREW 4X60 TRILBULAR 5PK	2	
048	415634-0	BAFFLE PLATE 9031/9032	1	
049	211028-5	BALL BEARING 627LB/N1923BD/903	1	
050	681614-0	INSULATION WASHER 627/N1923BD/	1	
051	517146-0	ARMATURE ASSY 110V 9031 INC. 49,50,52,53	1	115V
052	241884-9	FAN 60 TW0350	1	
053	210005-4	BALL BEARING 608DDW 4157KB HR3000C/JN1601/9016B/PC1100	1	UB1101
A01	794109-5	ABRASIVE BELT 30X533 AA40	1	
A02	794111-8	ABRASIVE BELT 30X533 AA60	1	
A03	794113-4	ABRASIVE BELT 30X533 AA80	1	
A04	794115-0	ABRASIVE BELT 30X533 AA100	1	
A05	794117-6	ABRASIVE BELT 30X533 AA120	1	
E01	652259-1	CLAMP WASHER 1902/9046	4	
E02	655030-2	*PLUG UK TYPE 2107F/JR3050T HM1810/HR2432/JR3060T/3070CT	1	115V
E03	654091-9	NON INSULATED TERMINAL LC1230 N910/RP0910/HM1810/HR2432/JR3060T/3070CT	1	115V

SPARE PARTS LIST

MODEL NO. 9031

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
E04	654077-3	INSULATED TERMINAL FV2-M3	2	
E07	344571-0	FRONT COVER 9031	1	
E08	654051-1	EARTH TERMINAL 1902/UH4500	1	

SERVICE DRAWING

MODEL NO. 9031

