


Model No.DMR110W JOB SITE RADIO



POS. NO.	PART NO.	DESCRIPTION	USED QTY	NOTES
001	SE00000325	SCREW PTB 3X8(NI)	6	
002-2	SE00000824	PCB A ASSEMBLY	1	
003	SE09090011	SCREW 1.7	6	
004	SE020PC020	POWER BUTTON HOLDER	1	
005	SE00000274	POWER BUTTON	1	
006	SE09090011	SCREW 1.7	7	
007	SE020PC030	PRESET BUTTON HOLDER	1	
008	SE00000275	PRESET BUTTON	1	
009	SE00000565	PCB-P ENCODER ASS'Y 07DB0A1	1	
010	SE00000193	SCREW 3X10	2	
011	SE00000566	PCB-P DC JACK ASS'Y 07PB0A1	1	
012	SE09064161	SCREW M4X16	1	
013	SE09064161	SCREW M4X16	1	
014	SE00000325	SCREW PTB 3X8(NI)	1	
015	SE09064161	SCREW M4X16	1	
016-1	SE00000308	FRONT CABINET ASS'Y	1	
017	SE00000325	SCREW PTB 3X8(NI)	1	
018	SE09064161	SCREW M4X16	1	
019	SE00000159	FRONT BUMPER	1	
020	SE00000160	SCREW PTHE6X47(CR)	4	
021	SE0338PC5Z	FRONT BAR	2	
022	SE00000042	JACK COVER	1	
023	SE21B1110A	ROTARY KNOB RING	1	
024	SE09173106	HEX SCREW M3X10	1	
025	SE00000465	ROTARY KNOB BLK 3102PC0000040	1	
026	SE09176166	HEX SCREW M6X16	2	
027	SE00000162	BATTERY COVER BUMPER	1	
028	SE09176166	HEX SCREW M6X16	2	
029	SE00000165	REAR BUMPER	1	
030	SE00000167	BATTERY COVER	1	
031	SE00000325	SCREW PTB 3X8(NI)	2	
032	SE00000168	PACKING	1	
033	SE00000571	BACK UP BATTERY COVER (WHT) 31	1	
034	SE00000176	SCREW PTHE6X20(CR)	1	
035	SE09176166	HEX SCREW M6X16	1	
036	SE00000178	HANDLE HOLDER (R)	1	
037	SE00000184	SPRING	2	
038	SE09994007	STEEL BALL	2	
039	SE00000179	HANDLE	1	
040	SE00000181	HANDLE HOLDER (L)	1	
041	SE00000176	SCREW PTHE6X20(CR)	1	
042	SE09176166	HEX SCREW M6X16	1	

043		SE00000184	SPRING	2	
044		SE09994007	STEEL BALL	2	
045		SE00000190	BATTERY COVER LOCKER	1	
046		SE00000284	RUBBER ANT 174-240(BLACK)	1	
047		SE021J9032	ROD ANT HOLDER	1	
048		SE024J9050	PACKING	1	
049		SE021PC050	LOCKER FIXER PIN 62.8	1	
050		SE021PC040	LOCKER FIXER PIN 79.5	1	
051		SE00000067	LOCKER HINGER	1	
052		SE00000828	REAR CABINET(WHITE)ASS'Y	1	
053		SE09163452	SCREW M3X45	1	
054		SE00000187	HANDLE SUS-PLATE (R)	1	
055		SE09163452	SCREW M3X45	1	
056		SE021PC030	BATTERY COVER LOCKER	1	
057		SE024J9030	PACKING	1	
058		SE01620771	SPEAKER	1	
059		SE024J9070	PACKING	4	
060		SE09090023	SCREW M4X12	4	
061		SE024J9090	PACKING	4	
062		SE00000205	SPEAKER NET ASSY	1	
063		SE024J9040	PACKING	4	
064		SE9076146A	HEX SCREW M6X14	4	
065		SE00000579	PCB-P AUX ASS'Y 07BB0A1	1	
066		SE00000193	SCREW 3X10	2	
067		SE00000285	PCB-G USB ASS'Y	1	
068		SE00000193	SCREW 3X10	2	
069		SE00000192	HANDLE SUS-PLATE(L)	1	
070		SE9076146A	HEX SCREW M6X14	4	
071		SE024J9040	PACKING	4	
072		SE00000205	SPEAKER NET ASSY	1	
073		SE024J9090	PACKING	4	
074		SE01620771	SPEAKER	1	
075		SE09090023	SCREW M4X12	4	
076		SE024J9070	PACKING	4	
077		SE024J9030	PACKING	1	
078		SE00000291	GROUND PLATE	1	
079		SE021J9010	SPEAKER HOLDER	1	
080		SE021PC100	ROD ANT TERMINAL	1	
081		SE021P0020	NUT	1	
082		SE00000199	SILICON RUBBER WASHER	2	
083		SE00000193	SCREW 3X10	2	
084		SE00000199	SILICON RUBBER WASHER	2	
085		SE00000193	SCREW 3X10	1	