


EBH341U



REF.	CODE	DESCRIPTION	UNIT	LIST	REF.	CODE	DESCRIPTION	UNIT
1	961057-5	RETAINING RING S-17	PC		61	962105-3	RETAINING RING R-26	PC
2	922331-6	HEX. SOCKET HEAD BOLT M6X20	PC		62	922353-6	HEX SOCKET HD BOLT M6X30	PC
3	318421-5	CLUTCH CASE	PC		63	265590-2	+HEX BOLT M8X10 WITH R	PC
4	451157-4	SPACER	PC		64	210081-8	BALL BEARING 629ZZ	PC
5	211338-0	BALL BEARING 6003LLU	PC		65	140040-7	CUTTER SHAFT COMP	PC
6	962153-2	RETAINING RING R-35	PC		65		INC. 66, 67	
7	165577-3	CLUTCH DRUM	PC		66	227554-4	SPIRAL BEVEL GEAR 19	PC
8	195144-0	STAND SET	PC		67	325677-3	CUTTER SHAFT	PC
8		INC. 9			68	210116-5	BALL BEARING 6201LLU	PC
9	911218-7	PAN HEAD SCREW M5X14	PC		69	962151-6	RETAINING RING R-32	PC
10	961151-3	RETAINING RING S-32	PC		70	331860-2	RECEIVE WASHER	PC
11	424204-4	DAMPER	PC		71	346084-7	CLAMP WASHER	PC
12	318453-2	PIPE RETAINER	PC		72	168526-9	CUP	PC
13	922231-0	HEX. SOCKET HEAD BOLT M5X20	PC		73	264025-0	HEX NUT M10-17	PC
14	318454-0	PIPE BRACKET	PC		74	125545-8	CONTROL LEVER ASSY	PC
15	922331-6	HEX. SOCKET HEAD BOLT M6X20	PC		74		INC. 75-88, 233	
16	922201-9	HEX. SOCKET HEAD BOLT M5X8	PC		75	451086-1	LEVER CASE L	PC
17	443146-3	FELT RING 8	PC		76	233540-5	TORSION SPRING 11	PC
18	922341-3	HEX. SOCKET HEAD BOLT M6X25	PC		77	451084-5	THROTTLE LEVER	PC
19	318422-3	PIPE CLAMP	PC		78	233541-3	TORSION SPRING 7	PC
20	318423-1	PIPE HOLDER	PC		79	451083-7	LOCK OFF LEVER	PC
21	233202-5	COMPRESSION SPRING 20	PC		80	451213-0	CORRUGATE TUBE	PC
22	318424-9	HANDLE HOLDER	PC		81	168539-0	CONTROL CABLE	PC
23	318425-7	HANDLE CLAMP	PC		82	451081-1	CABLE HOLDER	PC
24	168524-3	KNOB 57	PC		83	451082-9	SWITCH LEVER	PC
25	922256-4	HEX. SOCKET HEAD BOLT M5X35	PC		84	232251-9	LEAF SPRING	PC
26	266326-2	TAPPING SCREW 4X18	PC		85	451085-3	SWITCH COVER	PC
27	451088-7	GRIP L	PC		86	638663-8	LEAD UNIT	PC
28	451089-5	GRIP R	PC		87	451087-9	LEVER CASE R	PC
29	331863-6	HANDLE 22	PC		88	266326-2	TAPPING SCREW 4X18	PC
31	922256-4	HEX. SOCKET HEAD BOLT M5X35	PC		89	318614-4	BLOWER HOUSING	PC
32	451525-1	WIRE CLAMP	PC		90	922223-9	HSH BOLT M5X16 WITH WR	PC
33	325675-7	SHAFT	PC		93	267424-5	FLAT WASHER 8	PC
34	810500-0	CAUTION LABEL	PC		94	267832-0	WAVE WASHER 10	PC
35	816551-1	SERIAL NO. LABEL	PC		95	266571-9	SHOULDER HEX BOLT M8X23	PC
36	140042-3	SHAFT PIPE COMPLETE	PC		96	168563-3	CLUTCH SHOE	PC
36		INC. 37,38			97	231863-5	TENSION SPRING 9	PC
37	331865-2	SHAFT PIPE	PC		98	265577-4	HEX HD BOLT M6X16	PC
38	140043-1	BUSH COMPLETE	PC		99	318611-0	FLYWHEEL	PC
38		INC. 39,40			100	168501-5	IGNITION COIL	PC
39	214048-8	PLANE BEARING 8	PC		101	922138-0	HSH BOLT M4X20 WITH WR	PC
40	424205-2	DAMPER	PC		102	324891-8	PLUG CAP SPRING	PC
41	125558-9	HANGER ASSEMBLY	PC		103	424105-6	PLUG CAP	PC
41		INC. 42-46			104	638664-6	LEAD UNIT	PC
42	451159-0	HANGER SPACER	PC		105	638665-4	LEAD UNIT	PC
43	162278-4	HANGER	PC		106	424313-9	GROMMET	PC
44	451158-2	HANGER STOPPER	PC		107	345963-6	CLAMP	PC
45	922233-6	HEX. SOCKET HEAD BOLT M5X20	PC		108	819312-8	MAKITA LOGO LABEL	PC
46	931202-6	HEX. NUT M5	PC		109	451876-3	PLUG COVER	PC
47	451091-8	PROTECTOR	PC		110	266572-7	# NAME?	
48	266326-2	TAPPING SCREW 4X18	PC		111	808633-3	4 STROKE INDICATION LABEL	PC
49	346074-0	CUTTER	PC		112	265187-7	PAN HD SCREW M5X12	PC
50	451092-6	PROTECTOR EXTENSION	PC		113	451875-4	CYLINDER COVER	PC
51	346072-4	PROTECTOR CLAMP	PC		114	266440-4	HEX SOCKET HD BOLT M5X40	PC
52	451090-0	PROTECTOR COVER	PC		115	265184-3	# NAME?	
53	922353-6	HEX. SOCKET HEAD BOLT M6X30	PC		116	345915-7	MUFFLER COVER	PC
54	922218-2	H.S.H. BOLT M5X14 WITH WR	PC		117	168469-5	EXHAUST MUFFLER	PC
55	125557-1	GEAR CASE ASSY	PC		118	345916-5	MUFFLER GASKET	PC
55		INC. 56-65,68-73			119	324980-9	SPARK ARRESTER	PC
56	318444-3	GEAR CASE	PC		120	266495-9	HEX SOCKET HD BOLT M5X14	PC
57	227553-6	SPIRAL BEVEL GEAR 13	PC		121	140419-2	ROCKER COVER COMP	PC
58	211064-1	BALL BEARING 6000	PC		122	162307-3	ROCKER COVER GASKET	PC
59	211062-5	BALL BEARING 6000ZZ	PC		123	168534-0	SPARK PLUG	PC
60	961006-2	RETAINING RING S-10	PC		124	162274-2	CAM GEAR COVER GASKET	PC