

SPARE PARTS LIST

PAGE 1

MODEL NO. JN1601

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	266053-1	*PT SCREW 4X35 JN1601 10PK	4	
002	159757-1	GEAR HOUSING COMPLETE	1	
003	331438-1	ROD JN1601	1	
004	212222-2	NEEDLE BEARING 1612 JN1601	1	
005	322704-7	CRANK SHAFT JN1601	1	
006	226286-0	SPUR GEAR 34 JN1601	1	
007	253215-0	*THIN WASHER 8 5093D 5PK	1	
008	159758-9	GEAR HOUSING COVER COMPLETE INC. 10	1	
009	210005-4	BALL BEARING 608DDW 4157KB HR3000C/JN1601/9016B/PC1100	1	UB1101
010	263002-9	RUBBER PIN 4/9402/HR160DWH/903HM1202C/BO3700	1	
011	241875-0	*FAN 54 4334D/4304/4305	1	
012	517511-3	ARMATURE ASSY 110V JN1601 INC. 9,11,13,14	1	110V
013	681636-0	INSULATION WASHER DP4003/4304 HR2432	1	
014	211021-9	BALL BEARING 607LLB 4305/9522NLS800DWB/HR2432	1	
015	421479-6	RUBBER RING 19 9541/9542/6823	1	
016	857617-8	NAME PLATE JN1601	1	
017	159755-5	MOTOR HOUSING COMPLETE 9520NB/	1	
018	415303-3	SWITCH KNOB 9540/9541/9522NB	1	
019	635011-2	FIELD 110V JN1601	1	110V
020	415490-8	BAFFLE PLATE 9520NB/9522NB	1	
021	254002-0	*WOODRUFF KEY 3 10PK	1	
022	267133-6	*THIN BLUE WASHER 6 LC1230 5PK	1	
023	226123-8	GEAR COMPLETE 13-37 JN1601	1	
024	266026-4	*CT SCREW M4X12 LC1230 5PK	1	
025	344116-4	STOPPER JN1601	1	
026	256111-1	PIN 6 HM1303B/HM1304/JN1600	1	
027	322703-9	RAM JN1601	1	
028	322702-1	PUNCH HOLDER JN1601	1	
029	265880-3	*CONE POINT BRUB SCREW 10PK M5X8	1	
030	A-83951	PUNCH JN1601	1	
031	A-15051	DIE JN1601	1	
032	322701-3	DIE HOLDER JN1601	1	
033	266080-8	*CAP HD SCREWM3X12OLTM3x12 5PK	2	
034	322748-7	LOCK NUT JN1601	1	
035	266060-4	*PT SCREW 4X65 TRILBULAR 5PK	2	
036	819063-3	MAKITA LABEL 500 4305/HR160DW 6313DW/6704D/05D/HR2432	1	
037	643922-7	BRUSH HOLDER 9520NB/9522NB	2	
038	191940-4	CARBON BRUSH CB-411	1	
039	643550-8	BRUSH HOLDER CAP CB-9-14-17/N1	2	
040	651418-4	SWITCH 9541/BO6040/GD0810C/956	1	
041	233071-4	*COMPRESSION SPRING 4 10PK	1	
042	415541-7	SWITCH LEVER 9520NB/9522NB	1	
043	645253-0	NOISE SUPPRESSOR RP1100/HK0500DA3000R/HR2432/JR3050T	1	
044	687069-7	SUPPORT 9520NB/9522NB	1	
045	682540-6	CORD GUARD 6906/9047/9049/2414LF1000	1	
046	665905-7	POWER SUPPLY CORD 1.0-2-2.0	1	110V
047	687052-4	STRAIN RELIEF 4157KB/2414B/JR3LS1230/BO6040/190/GD0800C/2432	1	
048	265995-6	*PT SCREW 4X18 10PK LF1000	2	
049	415540-9	REAR COVER 9520NB/9522NB	1	
050	266053-1	*PT SCREW 4X35 JN1601 10PK	2	
A01	781028-4	WRENCH 32 UM401DW	1	
A02	783208-8	HEX WRENCH 2.5 2012NB/JN1601	1	
E01	654531-7	TERMINAL BLOCK 2P N910/9541/TWRP1100C	1	
E02	655030-2	*PLUG UK TYPE 2107F/JR3050T HM1810/HR2432/JR3060T/3070CI	1	110V

SPARE PARTS LIST

MODEL NO. JN1601

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
E03	654091-9	NON INSULATED TERMINAL LC1230 N910/RP0910/HM1810/HR2432/JR30110V		
E04	654128-2	EARTH TERMINAL 9520NB/952/6826HR2432	1	

SERVICE DRAWING

PAGE 1

MODEL NO. JN1601

