



GARDEN HOSE REEL 60M CAPACITY

MODEL NO: **GH60A**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

- ❑ **WARNING!** Disconnect the hose reel from the water supply before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the hose reel in good condition.
- ✓ Replace or repair damaged parts. *Use recommended parts only. Unauthorised parts may be dangerous and will invalidate the warranty.*
- ✗ **DO NOT** operate the hose reel if any parts are damaged or missing as this may cause failure and/or personal injury.
- ✗ **DO NOT** use for any purpose other than that for which it is designed.
- ✗ **DO NOT** operate the hose reel when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✗ **DO NOT** direct water from the water hose at yourself or others.

2. INTRODUCTION

Lightweight tubular steel frame with tough plastic snap-together parts - no tools required. Integral handle for easy use and portability. Two angled 1/2" hose connectors that will fit most pipe systems. Reel holds up to 60m of Ø13mm hose.

3. CONTENTS


- 3.1. Check parts against the parts list below. If anything is missing, contact your Sealey stockist.

PART NO.	DESCRIPTION		QTY
1	Stand Holder		2
2	Metal Stand (longer)		2
3	Metal Handle (shorter)		1
4	Reel		2


PART NO.	DESCRIPTION		QTY
5	Reel Cross Bar		2
6	Crank Handle		1
7	Elbow Hose Connector Set		1
8	Male Adaptor		1

NOTE: HOSEPIPE NOT INCLUDED.


4. ASSEMBLY




Attach the handle and feet to the stand holder (fig.1).



Attach the two reels together using the two cross bars (fig.2).



Attach the crank handle through the stand holder (fig.3).



Attach the hose and connectors (fig.4).



To fit your hosepipe to the reel, simply connect your hose to the hose end connector inside the reel, and wind the hose in. To connect your reel to your water source, you will need to either cut a length from your garden hose or use an individual extension hose, then fix the hose to the outside of the reel using a hose end connector and attach the other end to your tap using a hose end connector and tap connector.

NOTE: Hosepipe not included.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR PURCHASE HERE

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk