



# PARTS CLEANING TANK EXTRA DEEP 136LTR

MODEL NO: **SM40D.V2**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection




Wear protective gloves

## 1. SAFETY

### 1.1. ELECTRICAL SAFETY

- WARNING!** It is the responsibility of the owner and the operator to read, understand and comply with the following: You must check all electrical products, before use, to ensure that they are safe. You must inspect power cables, plugs, sockets and any other connectors for wear or damage. You must ensure that the risk of electric shock is minimised by the installation of appropriate safety devices. A Residual Current Circuit Breaker (RCCB) should be incorporated in the main distribution board. You must also read and understand the following instructions concerning electrical safety.
- ✓ Ensure that cables are always protected against short circuit and overload.
- ✓ Regularly inspect power supply cables and plugs for wear or damage and check all connections to ensure that none are loose.
- ✓ Ensure that the voltage marked on the appliance matches the power supply to be used and that the plug is fitted with the correct fuse - see fuse rating at right.
- \* **DO NOT** use worn or damaged cables, plugs or connectors. Have any faulty item repaired or replaced immediately by a competent electrician.
- ✓ It is recommended that this heater is wired directly to a fused isolator switch. If, however, a plug is fitted, the following applies:
- ✓ Fit a new plug according to the following instructions (UK only).
  - a) Connect the GREEN/YELLOW earth wire to the earth terminal 'E'.
  - b) Connect the BROWN live wire to the live terminal 'L'.
  - c) Connect the BLUE neutral wire to the neutral terminal 'N'.
  - d) After wiring, check that there are no bare wires, that all wires have been correctly connected, that the cable restraint is tight.



### 1.2. GENERAL SAFETY

- WARNING!** Ensure Health & Safety, local authority and general workshop practice regulations are adhered to when using this equipment.
- ✓ Familiarise yourself with the application, limitations and potential hazards of the cleaning tank.
- WARNING!** Disconnect the cleaning tank from the mains power before changing accessories, servicing or performing any maintenance.
- ✓ Maintain the cleaning tank in good condition (use an authorised service agent).
- ✓ Replace or repair damaged parts. Use genuine parts only. Unauthorised parts may be dangerous and will invalidate the warranty.
- ✓ Locate the cleaning tank in a suitable work area. Ensure that the tank stands on a firm level surface. Keep the area clean and tidy and free from unrelated materials. Ensure that the area is well ventilated and has adequate lighting.
- ✓ Keep the cleaning tank away from heat sources such as heater, sparks, open flames etc.
- ✓ Ensure that there are no flammable or combustible materials near the work area.
- \* **DO NOT** use the cleaning tank where there are flammable liquids, solids or gases (e.g. paint solvents).
- ✓ In case of fire in the unit, **DO NOT** attempt to remove parts, or move the tank. The lid is fused and will close automatically to extinguish the flames.
- ✓ In case of fire in tank, **DO NOT** attempt to move unit or remove parts from tank. The lid is fusible and will automatically close extinguishing fire.
- ✓ **When cleaning parts ensure that nothing in the tank, including any parts basket, is in a position that would prevent the lid from closing fully if and when the fusible link activates.**
- \* **DO NOT** use any solvent with a flash point below 140°F. We recommend you use Sealey Degreasing Solvent (AK25), contact your local stockist for details.
- WARNING!** Only to be used with water soluble cleaning agents.
- WARNING!** Always wear approved eye or face protection when operating the cleaning tank.
- ✓ Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and contain long hair.
- ✓ Wear appropriate protective clothing.
- ✓ Maintain correct balance and footing. Ensure the floor is not slippery and wear non-slip shoes.
- ✓ Keep children and unauthorised persons away from the work area.
- ✓ Avoid accidental starting of the pump by ensuring the unit is unplugged from the mains power when not in use.
- \* **DO NOT** use the cleaning tank for any purpose other than that for which it is designed.
- \* **DO NOT** use cleaning tank in wet or damp locations or areas where there is condensation.
- \* **DO NOT** allow untrained persons to operate the cleaning tank.

- ✘ **DO NOT** over fill the cleaning tank with solvent.
- ✘ **DO NOT** operate the cleaning tank if any parts are missing or damaged as this may cause failure and/or personal injury.
- ✘ **DO NOT** modify the tank lid or jam it open as this will render the fusible fire link inoperative, which is dangerous and will invalidate the warranty and your insurance.
- ✘ **DO NOT** leave the cleaning tank operating unattended.
- ✘ **DO NOT** operate the cleaning tank when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- ✘ **DO NOT** smoke while working with, or near, the tank.
- ✓ The tank is not suitable for paint thinners, gun wash or air drying.
- ✓ When not in use switch off the cleaning tank and remove plug from the power supply.
- ✓ Dispose of waste liquids in accordance with local authority regulations.
- ✓ Keep the tank clean. Remove and clean the filter regularly for best and safest performance.
- ☐ **WARNING! DO NOT** allow the uncontrolled discharge of fluids which will pollute the environment.

## 2. INTRODUCTION

Heavy duty one piece steel tank. Extra deep tank is suitable for soaking and cleaning awkwardly shaped components. Fitted with fully sealed, magnetic drive pump unit. Lid of tank fitted with fusible link which automatically snaps lid shut in the event of fire. Supplied with removable shelf and parts basket.

## 3. SPECIFICATION

Model No: . . . . . SM40D.V2  
 Overall Height: . . . . . 1030mm  
 Tank Length: . . . . . 900mm  
 Tank Width: . . . . . 560mm  
 Tank Height: . . . . . 400mm  
 Pump Output: . . . . . 300-480ltr  
 Motor Power: . . . . . 15W  
 Supply: . . . . . 230V  
 Weight: . . . . . 43.4kg  
 Maximum Working Capacity: . . . . . 136ltr  
 Minimum Working Capacity: . . . . . 91ltr  
 Parts Cleaning Brush and Hose. . . . . SM201



## 4. ASSEMBLY

As you unpack the tank, check the contents against the parts list. If there are any damaged or missing parts contact your supplier immediately.

- 4.1. Open carton and remove lower shelf. Open tank lid and remove the pump housing set (in box), parts basket and legs. Close lid of tank and close carton flaps.
- 4.2. Carefully turn the carton upside down and open the bottom.
- 4.3. Assemble the legs to the brackets on the bottom of the tank with pan screws, spring washers and hex nuts (hand tight only).
- 4.4. Fit the lower shelf between the four legs and fix with pan screws, spring washers and hex nuts. Level shelf and then tighten the screws.
- 4.5. Tighten the leg mounting screws and turn the assembled unit upright. Remove the outer carton.
- 4.6. Open the lid and place the electrical pump switch housing through the rectangular hole in the side of the tank. Push down to locate.
- 4.7. Place the work shelf onto the two welded supports inside the tank.
- 4.8. Screw the 90° connector into the pump housing, then fit the flexible tube to the 90° connector.
- 4.9. Place the parts basket on the work shelf. Check the installation to ensure that the unit is ready for use.

## 5. OPERATING INSTRUCTIONS

- ☐ **WARNING! Ensure you read, understand and apply Section 1 safety instructions before using the tank.**
  - 5.1. Check that the pump power switch is in the 'Off' position and that the unit is unplugged from the mains power supply.
  - 5.2. Check that the drain plug is fitted and tight in the base of the tank.
  - 5.3. Pour the required amount of Sealey solvent, or a general purpose degreaser (contact your local stockist for supply), into the tank.
    - ✘ **DO NOT** use any other type of solvent. **CAUTION!** Ensure you follow any instructions provided with the solvent.
  - 5.4. Plug into the mains power supply and switch on the pump. Check that solvent flows freely through the flexible spigot.
  - 5.5. Place parts to be cleaned into the cleaning basket. Direct spray nozzle onto parts. Ensure any splash back stays inside the tank. Reposition the spray nozzle if necessary. For ground-in marks, leave the parts to soak in the bottom of the tank. Use a cleaning brush if required. Turn off the pump and leave the parts to drain either in the basket or, if too large, on the shelf.
  - 5.6. When finished, turn off the pump and unplug from the mains power supply.
    - ☐ **WARNING! DO NOT** allow the uncontrolled discharge of fluids which will pollute the environment. Dispose of waste liquids in accordance with local authority regulations.
  - 5.7. Keep the cleaning tank clean. Remove and clean the filter regularly for best and safest performance.
- NOTE:** When cleaning parts ensure that nothing in the tank, including any parts basket, is in a position that would prevent the lid from closing fully if and when the fusible link activates.



#### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

**Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR**



**01284 757500**



**01284 703534**



**sales@sealey.co.uk**



**www.sealey.co.uk**