



INSTRUCTIONS FOR

AIR HAMMER ADAPTOR FOR INJECTOR PULLER

MODEL NO: **VS2074**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instruction manual



Wear eye protection



Wear ear protection



Wear protective gloves

1. SAFETY

- WARNING!** Ensure Health and Safety, local authority and general workshop practice regulations are adhered to when using tools.
- WARNING!** Always use caution when working around fuel systems. The fuel in the fuel rail may be pressurised even if the engine is not running.
IMPORTANT: These instructions are provided as a guide only. Always refer to the vehicle manufacturer's service instructions, or a proprietary manual, to establish the current procedure and data, also any warnings or cautions particular to the vehicle.
- × **DO NOT** use the puller if any parts are missing or damaged.
- × **DO NOT** use this puller for any purpose other than that for which it is designed.
- × Switch off vehicle's ignition and disconnect the battery before commencing work under the bonnet.
- × Never lay tools on the vehicle's battery. This may short the terminals together, causing harm to yourself, the tools, or the battery.
- × Operate in a well ventilated area. Do not inhale fuel vapours.
- × Wear approved eye protection. A full range of personal safety equipment is available from your Sealey dealer.
- × Wear suitable clothing to avoid snagging. Do not wear jewellery and tie back long hair.
- × Keep children and other unauthorised persons away from the working area.
- × Keep yourself, tools, and test equipment away from hot engine parts.
- × Always keep a fire extinguisher close by, that is suitable for fuel/electrical/chemical fires.
- × **NEVER** smoke or have open flames near vehicle.
- ✓ Always relieve fuel pressure before disconnecting fuel lines from injectors.
- ✓ Use a rag to cover fuel line fittings, when connecting or disconnecting fuel lines. Avoid contact with fuel.
- ✓ Clean up all fuel spills immediately and dispose of all rags properly.
- ✓ Maintain the tool components in good and clean condition for best and safest performance.
- ✓ When work on the vehicle is finished, ensure all connections on vehicle are restored, and that there are no tools left in the engine bay.
- ✓ Store in a safe, dry, childproof location.

2. INTRODUCTION

For use with Sealey injector puller slide hammer sets Model no's VS2059, VS2064 or similar tool that has a minimum 350mm shaft length and suitable air hammer. Adaptor allows the air hammer to be used, to vibrate the injector loose instead of using a slide hammer. Ideal for stubborn injectors when an alternative method of removal is required. Supplied in storage case.


3. SPECIFICATION

Model no: **VS2074**
Adaptor shank size:.....401" Parker Taper



4. OPERATION

- 4.1. Follow the instructions of the injector puller kit to remove the particular injector/component fitted to the vehicle.
- 4.2. Instead of fitting the slide hammer to the shaft, fit the clamp and tighten the two hex headed screws to retain it in place against the handle.
- 4.3. Insert the adaptor into the air hammer.
- 4.4. Connect the shaft assembly onto the injector/component to be removed.
- 4.5. Insert the adaptor/air hammer into the clamp and hold the hammer with one hand and the handle with the other.
Note: DO NOT point the tool at the face.
- 4.6. Use the air hammer for short bursts on a low setting increasing the vibration level as required.
Note: DO NOT use the trigger lock setting.
- 4.7. As the injector begins to move reduce the upward pressure so the the tool does not fly out.



Environmental Protection
Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment.
When the product becomes completely unserviceable and requires disposal, drain off any fluids (if applicable) into approved containers and dispose of the product and the fluids according to local regulations.

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Sole UK Distributor, Sealey Group.
Kempson Way, Suffolk Business Park,
Bury St. Edmunds, Suffolk.
IP32 7AR



01284 757500



01284 703534



www.sealey.co.uk



sales@sealey.co.uk