



Item	Part No.	Description
1	SMIG140.27	HANDLE FRAME
2	140XT.02	CASE
3	140XT.03	BACK PANEL
4	140XT.04	FAN
5	140XT.05	BOTTOM PANEL
6	140XT.06	FRONT PANEL
7	250XTD.28	CABLE HOLDER
8	140XT.08	WORK CLAMP
9	140XT.09	ELECTRODE HOLDER CABLE
11	140XT.11	MAIN SWITCH
12	140XT.12	INDICATOR
13	140XT.13	HAND WHEEL
14	140XT.14	POINTER

Item	Part No.	Description
15	140XT.15	SHUNT BRACKET
16	140XT.16	SHUNT
--	180XT.14	TOP COVER (NOT SHOWN)
17	140XT.17	CLIP
18	140XT.18	LEAD SCREW PIN
19	140XT.19	HEAT RELAY
20	140XT.20	HEAT CONDUCTOR
21	140XT.21	TRANSFORMER
22	140XT.22	TRANSPARENT PLATE
23	140XT.23	FRAME
24	140XT.V2-24	HEAT RELAY
--	140XT.24	CHIPPING HAMMER/WIRE BRUSH (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.