



Item	Part No.	Description	Qty
1	ASC120.01	Inner Rod	1
2	ASC120.02	Load Pin Assembly (c/w Hitch Pin)	1
4	ASC120.04	Snap Ring	1
5	ASC120.05	Main Spring	1
6	ASC120.06	Stand Base Leg	3
7	HHB12100.S	Hex Head Bolt M12 x 100mm	3
10A	ASC120.10A	Castor Wheel Assembly (75 x 30 x 10 x 265)(c/w Bolt, Spring & Link Tube)	3

Item	Part No.	Description	Qty
11	ASC120.11	Crutch Head 'U' (Long)	1
12	ASC120.12	Crutch Head 'U' (Short)	1
13	ASC120.13	Crutch Head 'V'	1
--	ASC120.14	Cross Member (Not Shown)	--
--	ASC120.15	Bracket (Not Shown)	--
--	ASC120.06-10	Stand Base Assembly (Not Shown)	--

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.