



Item	Part No.	Description
1	DG10164	Cooking Plate Foot (Inc Screw)
3	DG10165	Grease Collection Tray
4	DG10166	Cooking Plate
5	DG10167	Control Knob

Item	Part No.	Description
7	DG10172	Piezo-Ignitor c/w Wire
--	DG10001	Uk Regulator & Hose (c/w knob) 37mbar (Not Shown)
--	DG10168	Burner (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.