


Parts Information:

Vacuum Cleaner Wet & Dry 30L 1100W/230V

Model No: PC300.V2



Item	Part No.	Description
1	PC300.V2-01	Top Handle
2	PC300.V2-02	Switch
3	PC300.V2-03	Top Cover
4	PC300.V2-04	Thermal Baffle
5	PC300.V2-05	Motor
7	PC300.V2-07	Tank Latch
8	PC300.V2-08	Lower Cover
9	PC300.V2-09	Filter Cage Assembly
10	PC300.V2-10	Tank
11	PC300.V2-11	Hose Inlet

Item	Part No.	Description
12	PC300.V2-12	Drain Cap
13	PC300.V2-13	Castor Wheel Assembly
14	PC300V2CF	Cartridge Filter for PC300.V2
15	PC300V2DB	Dust Bag Pack of 3'
ACC1	PC300.V2-ACC1	Hose
ACC2	PC300.V2-ACC2	Extension Tube
ACC3	PC300.V2-ACC3	Crevice Nozzle
ACC4	PC300.V2-ACC4	Wet/Dry Nozzle
ACC5	PC300.V2-ACC5	Floor Brush

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk

