



Item	Part No.	Description
1	PM120L.01	Output Shaft
2	PM120L.02	Woodruff Key 5 x 10mm
3	PM120L.03	Oil Seal (22x32x7mm)
4	PM120L.04	Head, Housing
5	SB-4.0	Steel Ball 4.0mm
6	PM120L.06	Spring
7	PM120L.07	Control Knob
8	PM120L.08	Screw ST3 x 12mm
9	B/6002-2RS	Bearing 6002-2RS
10	PM120L.10	Retaining Ring Ø32mm
11	PM120L.11	Retaining Ring Ø15mm

Item	Part No.	Description
12	PM120L.12	Gear (Large)
13	PM120L.13	Retaining Ring Ø13mm
14	B/HK0810	Needle Bearing HK0810
15	PM120L.15	Output Shaft Spring
16	PM120L.16	Output Shaft Spring Cover
17	PM120L.17	Screw ST5 x 35mm
19	PM120L.19	Main Drive Shaft
20	PM120L.20	Diagonal Gear
21	PM120L.21	Shift Drive Set
22	PM120L.22	Shift Drive Plate

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:
120L Electric Paddle Mixer 1400W
Model No: PM120L & PM120L110V

Item	Part No.	Description
23	B/608-RS	Bearing 608-RS
26	PM120L.26	Reverse Drive Shaft
27	PM120L.27	Two-Way Gear
28	PM120L.28	Gasket
29	PM120L.29	Middle Cover
30	PM120L.30	O-Ring 27 x 2mm
31	PM120L.31	Rotor Spring
32	PM120L.32	Seal
33	B/609-2RS	Bearing 609-2RS
34	PM120L.34	Rotor
--	PM120L110V.34	Rotor (110V)
35	B/608ZZ	Bearing 608ZZ
36	PM120L.36	Fan Cover
37	PM120L.37	Screw ST5 x 65mm
38	PM120L.38	Stator
--	PM120L110V.38	Stator (110V)
39	PM120L.39	Protection Piece
40	MSP416.S	Machine Screw Pan Head Phillips M4 x 16mm
41	PM120L.41	Label
--	PM120L110V.41	Label (110V)
42	PM120L.42	Power Cable
--	PM120L110V.42	Power Cable (110V)
43	PM120L.43	Main Housing
44	PM120L.44	Cable Grip
45	PM120L.45	Cable Sleeve

Item	Part No.	Description
46	PM120L.46	Capacitor
--	PM120L110V.46	Capacitor (110V)
47	PM120L.47	Switch, On/Off Press Button 8A 250V
--	PM120L110V.47	Press Button On/Off Switch (110V)
48	PM120L.48	Button for Switch
49	PM120L.49	Pin for Switch Button
50	PM120L.50	Lock Button Base
51	PM120L.51	Push Button Spring
52	PM120L.52	Lock Cap
53	PM120L.53	Plastic Cover for Press Button Switch
54	PM120L.54	Potentiometer
55	PM120L.55	Carbon Brush Cover (Pair)
56	PM120L.56	Carbon Brush (Pair)(c/w Cover) (19.2 x 10.42 x 6.9 x 41.8mm)
--	PM120L110V.56	Carbon Brush (Pair) (19 x 10.41 x 6.93 x 40.6mm) (110V)
57	PM120L.57	Carbon Brush Holder (Pair)
58	PM120L.58	Main Housing Cover
59	PM120L.59	Block
--	PM120L110V.59	Block (110V)
60	PM120L.60	Screw ST3 x 12mm
61	PM120L.61	Back Cover
62	PM120L.62	Mixer Paddle
63	PM120L.63	Spanner 22mm
--	PM120L-64	Mixing Paddle (B) 140mm (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK

Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland

Tel: 01284 757500 · Email: sales@sealey.co.uk · Web: www.sealey.co.uk