


## Parts Information: Starter/Charger 420/60Amp 12/24V 230V Model No: START420



Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



## Parts Information: Starter/Charger 420/60Amp 12/24V 230V Model No: START420

| Item | Part No.    | Description                       |
|------|-------------|-----------------------------------|
| 1    | START800.01 | KNOB                              |
| 2    | SN8.S       | STEEL NUT M8 ZINC DIN934 (SINGLE) |
| 3    | FWM8.S      | FLAT WASHER M8 SINGLE             |
| 4    | START800.04 | TERMINAL PROTECTION COVER         |
| 5    | START420.05 | POWER SWITCH                      |
| 6    | START660.06 | CABLE GRIP                        |
| 7    | START420.07 | POWER CORD                        |
| 8    | START420.08 | NEGATIVE CABLE WITH CLAMP         |
| 9    | START660.09 | POSITIVE CABLE WITH CLAMP         |
| 10   | START420.10 | FRONT PLASTIC PANEL               |
| 11   | START420.11 | TOP PANEL                         |
| 12   | START660.12 | CABLE GRIP                        |
| 13   | SN8.S       | STEEL NUT M8 ZINC DIN934 (SINGLE) |
| 14   | START420.14 | COVER PANEL                       |
| 15   | START800.15 | SERRATED WASHER 8                 |
| 16   | START800.16 | INSULATING WASHER                 |
| 17   | START800.17 | TERMINAL BOLT M8                  |
| 18   | FWM8.S      | FLAT WASHER M8 SINGLE             |
| 19   | START420.19 | TRANSFORMER                       |
| 20   | START420.20 | THERMOSTAT (FOR TRANSFORMER)      |
| 21   | START420.21 | BOTTOM PANEL                      |
| 22   | START420.22 | INSULATING PLATE                  |
| 23   | START420.23 | FAN                               |

| Item | Part No.    | Description                       |
|------|-------------|-----------------------------------|
| 24   | START800.24 | HANDLE SUPPORT PANEL              |
| 25   | START800.25 | TOP PLASTIC COVER                 |
| 26   | START420.26 | BACK PANEL                        |
| 27   | START420.27 | RECTIFIER                         |
| 28   | START420.28 | THERMOSTAT (FOR RECTIFIER)        |
| 29   | START800.29 | INSULATING WASHER (A)             |
| 30   | SN6.S       | STEEL NUT M6 ZINC DIN934 (SINGLE) |
| 31   | FWM6.S      | FLAT WASHER M6 SINGLE             |
| 32   | SS635.S     | HEX HEAD SET SCREW M6x35mm SINGLE |
| 33   | START420.33 | AMMETER                           |
| 34   | START420.34 | SWITCH                            |
| 35   | START800.35 | INSULATING WASHER (B)             |
| 36   | FWM6.S      | FLAT WASHER M6 SINGLE             |
| 37   | START.F     | FUSE (SINGLE) 110A                |
|      | START.20F   | FUSE (PACK OF 20) 110A            |
| 38   | START800.38 | FUSE BOX                          |
| 39   | SWM12.S     | SPRING WASHER M12 ZINC (SINGLE)   |
| 40   | START800.40 | AXLE CAP                          |
| 41   | START800.41 | WHEEL                             |
| 42   | START800.42 | WHEEL AXLE                        |
| 43   | START660.43 | SHUNT                             |
| 44   | START800.44 | FOOT                              |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 01284 703534 sales@sealey.co.uk

www.sealey.co.uk