





09274 - Professional Fireball 1071DV Propane Heater

Exploded Diagram & Parts List



Ref. No.	Description	SIP Part No.	Ref .No.	Description	SIP Part No.
1.	Combustion chamber	PW09-10050	24.	Brass fitting	PW09-10013
2.	Cover	PW09-10085	25.	Fitting lock bracket	PW09-10070
3.	Front leg support	PW09-10052	26.	Nut	PW09-10012
4.	Rear leg support	PW09-10053	27.	Switch	PW09-10071
5.	Cable protection	PW09-10054	28.	Mains lead	PW09-10072
6.	Upper cover plate	PW09-10086	29.	Cable protection	PW09-10073
7.	Gas supply pipe	PW09-10056	30.	Piezo igniter	PW09-10074
8.	Elbow	PW09-10057	31.	Combustion head	PW09-10075
9.	Fan	PW09-10058	32.	Ignition electrode	PW09-10019
10.	Motor	PW09-10087	33.	H.T. Cable	PW09-10076
11.	Lock plate	PW09-10060	34.	Nozzle	PW09-10077
12.	Inlet grill	PW09-10061	35.	Circlip	PW09-10022
13.	Control box cover	PW09-10062	36.	Thermocouple	PW09-10078
14.	Handle	PW09-10063	37.	Thermocouple clip	PW09-10024
15.	Handle support	PW09-10064	38.	Thermostat holder	PW09-10025
16.	Electrics housing	PW09-10065	39.	Safety thermostat	PW09-10026
17.	Fuse holder	PW09-10066	40.	Gas hose	PW09-10079
18.	Fuse	PW09-10067	41.	Excess flow valve	PW09-10080
19.	Terminal block	PW09-10068	42.	Pressure regulator	PW09-10081
20.	Thermal gas valve	PW09-10017	45.	Voltage switch	PW09-10082
21.	Solenoid valve	PW09-10089	46.	Voltage switch cover	PW09-10083
22.	Solenoid coil	PW09-10090	47.	Outlet grill	PW09-10084
23.	Elbow	PW09-10057			