





09275 - Professional Fireball 1602DV Propane Heater

Exploded Diagram & Parts List



Ref. No.	Description	SIP Part No.	Ref. No.	Description	SIP Part No.
1.	Combustion chamber	PW09-10095	25.	Fitting lock bracket	PW09-10070
2.	Cover	PW09-10104	26.	Nut	PW09-10012
3.	Front leg support	PW09-10052	27.	Switch	PW09-10071
4.	Rear leg support	PW09-10053	28.	Mains lead	PW09-10072
5.	Cable protection	PW09-10054	29.	Cable protection	PW09-10073
6.	Upper cover plate	PW09-10086	30.	Piezo igniter	PW09-10074
7.	Gas supply pipe	PW09-10097	31.	Combustion head	PW09-10100
8.	Elbow	PW09-10057	32.	Ignition electrode	PW09-10019
9.	Fan	PW09-10098	33.	H.T. Cable	PW09-10076
10.	Motor	PW09-10106	34.	Nozzle	PW09-10101
11.	Lock plate	PW09-10060	35.	Circlip	PW09-10022
12.	Inlet grill	PW09-10061	36.	Thermocouple	PW09-10078
13.	Control box cover	PW09-10062	37.	Thermocouple clip	PW09-10024
14.	Handle	PW09-10063	38.	Thermostat holder	PW09-10025
15.	Handle support	PW09-10064	39.	Safety thermostat	PW09-10026
16.	Support plate	PW09-10065	40.	Gas hose	PW09-10079
17.	Fuse holder	PW09-10066	41.	Excess flow valve	PW09-10080
18.	Fuse	PW09-10067	42.	Pressure regulator	PW09-10081
19.	Terminal block	PW09-10068	45.	Voltage switch	PW09-10082
20.	Thermal gas valve	PW09-10017	46.	Voltage switch cover	PW09-10083
21.	Solenoid valve	PW09-10089	47.	Air flap	PW09-10102
22.	Solenoid coil	PW09-10090	48.	Air flap	PW09-10103
23.	Brass fitting	PW09-10069	49.	Outlet grill	PW09-10084
24.	Brass fitting	PW09-10013			