


# 09287 - Fireball 342 Propane Heater

## Exploded Diagram & Parts List



<i>Ref. No.</i>	<i>Description</i>	<i>Sip Part No.</i>	<i>Ref. No.</i>	<i>Description</i>	<i>Sip Part No.</i>
<b>1.</b>	<i>Front grill</i>	<i>PW09-10310</i>	<b>15.</b>	<i>Mains lead gland</i>	<i>PW09-10324</i>
<b>2.</b>	<i>Cover</i>	<i>PW09-10311</i>	<b>16.</b>	<i>Regulator (700mbar) c/w hose</i>	<i>PW09-10325</i>
<b>3.</b>	<i>Handle</i>	<i>PW09-10312</i>	<b>17.</b>	<i>Plastic cover</i>	<i>PW09-10326</i>
<b>4.</b>	<i>Terminal block</i>	<i>PW09-10313</i>	<b>18.</b>	<i>Base</i>	<i>PW09-10327</i>
<b>5.</b>	<i>Chamber</i>	<i>PW09-10314</i>	<b>19.</b>	<i>Gas valve button</i>	<i>PW09-10328</i>
<b>6.</b>	<i>Chamber bracket</i>	<i>PW09-10315</i>	<b>20.</b>	<i>Switch</i>	<i>PW09-10329</i>
<b>7.</b>	<i>Burner assembly</i>	<i>PW09-10316</i>	<b>21.</b>	<i>Piezo ignitor</i>	<i>PW09-10330</i>
<b>8.</b>	<i>Thermostat</i>	<i>PW09-10317</i>	<b>22-1.</b>	<i>Gas valve</i>	<i>PW09-10331</i>
<b>9.</b>	<i>Thermocouple</i>	<i>PW09-10318</i>	<b>22-2.</b>	<i>Solenoid valve</i>	<i>PW09-10332</i>
<b>10.</b>	<i>Fan</i>	<i>PW09-10319</i>	<b>22-3.</b>	<i>Gas pipe</i>	<i>PW09-10333</i>
<b>11.</b>	<i>Motor</i>	<i>PW09-10320</i>	<b>22-4.</b>	<i>Gas nozzle</i>	<i>PW09-10334</i>
<b>12.</b>	<i>Rear grill</i>	<i>PW09-10321</i>	<b>23.</b>	<i>Bracket</i>	<i>PW09-10335</i>
<b>13.</b>	<i>Mounting clip</i>	<i>PW09-10322</i>	<b>24.</b>	<i>Electrode</i>	<i>PW09-10336</i>
<b>14.</b>	<i>Mains lead</i>	<i>PW09-10323</i>			