


09296 – SIP 1830 Infrared Diesel / Paraffin Heater
   
 Exploded Diagram & Parts List



Ref. No.	Description	SIP Part No.	Ref. No.	Description	SIP Part No.	Ref. No.	Description	SIP Part No.
1.	Protective Plate	PW24-00006	28.	Flex diesel pipe	PW24-00031	55.	Cable fastener	PW24-00051
2.	Front Heat Disc	PW24-00007	29.	Suction pipe	95536	56.	Cable fastener nut	PW24-00052
3.	Insulating Barrel	PW24-00008	30.	Brass fitting	PW24-00032	57.	Ground terminal board	PW24-00053
4.	Combustion Chamber	PW24-00009	31.	Support Foot	PW24-00033	58.	230V Lamp	PW24-00054
5.	Rear Disc	PW24-00010	32.	Wheel axle	PW24-00034	59.	Flame control box	PW24-00055
6.	Upper Heat Canopy	PW24-00011	33.	Wheel	PW24-00035	60.	Thermostat plug	95558
7.	Spacer	PW24-00012	34.	Wheel Clips	95533	61.	Thermostat plug cover	PW24-00056
8.	Heater Body	PW24-00013	35.	Black wheel cover	95534	62.	Elbow connection	PW24-00057
9.	Handwheel	PW24-00014	36.	Danfoss Nozzle	PW24-00036	63.	Fan Duct / Cowl	PW24-00058
10.	Blast tube	PW24-00015	37.	Air flap	PW24-00037	64.	Fan	PW24-00059
11.	Terminal board	PW24-00016	38.	Diffuser ring	PW24-00038	65.	Fan support bracket	PW24-00060
12.	Pipe cap	PW24-00017	39.	Air Disc	PW24-00039	66.	Motor support bracket	PW24-00061
13.	Handle	PW24-00018	40.	Ignition electrode	93637	67.	Motor	PW24-00062
14.	Panel	PW24-00019	41.	Electrodes support stirrup	PW24-00040	68.	4 $\mu$ F Capacitor	PW24-00063
15.	Panel	PW24-00020	42.	Brass lock nut	PW24-00041	69.	Motor-pump coupling	93654
16.	Tank cap	95522	43.	Burner Support Disc	PW24-00042	70.	Fitting	PW24-00064
17.	Fuel Tank	PW24-00021	44.	Photoresistor support	PW24-00043	71.	Fitting	PW24-00065
18.	O-ring	PW24-00022	45.	Photocell	93655	72.	Danfoss Diesel pump	95563
19.	Drain cap	PW24-00023	46.	H.T. Cable connect.	PW24-00044	73.	Danfoss Solenoid coil	93512
20.	DX Panel	PW24-00024	47.	Cable protection	PW24-00045	74.	Danfoss Solenoid valve body	93653
21.	SX Panel	PW24-00025	48.	Micropipe	PW24-00046	72.	Suntec Diesel Pump	PW24-00066
22.	Panel	PW24-00026	49.	Safety thermostat	93533	73.	Suntec Solenoid coil	PW24-00067
23.	Lower Adj Heat Protector	PW24-00027	50.	Nozzle support	PW24-00047	74.	Suntec Solenoid valve body	PW24-00068
24.	Flex diesel pipe	PW24-00028	51.	Legend Plate	PW24-00048	75.	Solenoid valve cable	PW24-00069
25.	Clip	PW24-00029	52.	Switch	93627	76.	Cap with level control	09255
26.	Fuel Filter	PW24-00030	53.	Reset button	PW24-00049			
27.	Flex diesel pipe	93610	54.	Power cord	PW24-00050			