


# baridi

---

## 60cm Built-In Warming Drawer, Push-to-Open, Anti-Slip Mat, Black/Stainless Steel

---



**Model No. DH201 / DH202**

Thank you for purchasing a Dellonda product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

## Important Information

Please read these instructions carefully and note any safe operational requirements, warnings & cautions. Use the product correctly and with care for the purpose for which it is intended. Failure to do so may cause damage and/or personal injury and will invalidate the warranty. Keep these instructions safe for future use.



Refer to  
instruction  
manual



Warning:  
Hot  
Surface



Indoor use  
Only



Warning:  
Can cause  
Fire



Warning:  
Electricity

## SAFETY INSTRUCTIONS

### • ELECTRICAL SAFETY


- **WARNING!** It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using.
- Inspect power supply leads, plugs and all electrical connections for wear and damage.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- **DO NOT** use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a Sealey qualified technician.
- If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- Sealey recommend that an RCD (Residual Current Device) is used with all electrical products.
- **Important:** Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse.
- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.

### • GENERAL SAFETY

- When using electrical appliances, basic safety precautions should always be followed, including the following:
- **READ ALL INSTRUCTIONS.**
- **DO NOT** touch hot surfaces. Use handles or knobs.
- To protect against electric shock, **DO NOT** immerse cord, plugs, or appliance in water or other liquid.
- This appliance can be used by children aged from 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- **DO NOT** operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Bring it to a qualified technician for examination, repair or electrical or mechanical adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- **DO NOT** use outdoors.
- **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
- To disconnect from mains supply, end all function operations on the control panel. Then remove plug from wall outlet.
- **DO NOT** use appliance for other than intended use.
- **CAUTION HOT SURFACES:** This appliance generates heat and escaping steam during use. Proper precautions must be taken to prevent the risk of burns, fires, or other injury to persons or damage to property.
- **CAUTION:** This appliance is hot during operation and retains heat for some time after turning OFF.
- Always use oven mitts when handling hot materials and allow metal parts to cool before cleaning.
- All users of this appliance must read and understand this instruction manual before operating or operating or cleaning this appliance.
- The cord to this appliance should be plugged into a 220-240V AC electrical outlet only.
- If this appliance begins to malfunction during use, immediately turn the power off and unplug the cord. **DO NOT** use or attempt to repair the malfunctioning appliance.
- **DO NOT** leave this appliance unattended during use.
- **DO NOT** immerse power cord in any liquid. If the supply cord is damaged it must be replaced by the manufacturer or an authorized service agent or a qualified technician in order to avoid a hazard.
- Keep the cord out of reach from children and infants to avoid the risk of electric shock and choking.
- This appliance is intended to be used in household and similar applications as: staff kitchen areas in shops, offices and other working environments areas in shops, offices and other working environments, farm houses
- If the electrical circuit is overloaded with other appliances, your appliance may not operate properly. It should be operated on a separate electrical circuit from other appliances.


## INSTALLATION (FIG.1)

- The unit is designed to be a built-in appliance and must be fitted to meet all electrical regulations in force at the time.
- Fig.1 shows required housing dimensions.
- Two fixing screws are supplied to enable the unit to be screwed securely in place on the cabinet.



## OPERATION (FIG.1 FIG.2)

- To open the drawer and access controls, press the front panel in the middle (fig.1).
- **NOTE:** Before first use:
- Clean the surfaces with a soft damp cloth.
- To remove any residue from the warming drawer that may have been left from the manufacturing process, you should turn the control knob to the maximum temperature setting.
- It is perfectly normal for a smell to be produced during this process.
- You should make sure that any windows in the room are left open during this process.
- It is advisable for you not to remain in the room when burning off process is taking place.
- You should leave the warming drawer on the maximum setting for 2 hours
- To load the drawer, press the front panel in the middle (fig.1).
- Place crockery into the drawer.
- **NOTE:** Crockery load should not exceed 20 kg.
- Set time and temperature using the controls (fig.2).
- **NOTE:** Minimum time setting is 10 minutes, maximum is 120 minutes.
- **NOTE:** Temperature can be set between 30°C and 70°C.
- When power is turned on, the light (fig.2) illuminates.
- When the timer expires the heating will stop.
- **IMPORTANT:** Care should be taken when removing items from the warming drawer.
- When appropriate you should use oven gloves when removing items from the drawer.
- You should ensure that the appliance is switched off before removing crockery.
- Power consumption standby mode: N/A
- Power consumption off mode: 0W
- Time after which the equipment reaches automatically standby mode: N/A
- Time after which the equipment reaches automatically off mode: 0min



## Environment Protection, Waste Electrical and Waste Electronic Equipment Regulations (WEEE)



Recycle unwanted packaging materials. When this product is no longer required, or has reached the end of its useful life, please dispose of in an environmentally friendly way. Drain any fluids (if applicable) into approved containers, in accordance with local waste regulations. Please note that this product contains one or more batteries. It is our policy to continually improve products and we reserve the right to alter data, specifications and parts without prior notice. No liability is accepted for incorrect use of this product. Guarantee is 12 months from purchase date, proof of which is required for any claim.



## Dellonda Limited, Sole UK Distributor of Baridi

Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757575



support@dellonda.co.uk



www.dellonda.co.uk