

VARIABLE TEMPERATURE HEAT GUN KIT 2000W

MODEL NO: HS107K

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.









Refer to instruction manual

Wear a mask

Wear eye protection

Wear protective gloves

1. SAFETY

1.1. ELECTRICAL SAFETY

- WARNING! It is the user's responsibility to check the following:
- Check all electrical equipment and appliances to ensure that they are safe before using.
- √ Inspect power supply leads, plugs and all electrical connections for wear and damage.
- Ensure that the insulation on all cables and on the appliance is safe before connecting it to the power supply.
- DO NOT use worn or damaged cables, plugs or connectors.
- Ensure that any faulty item is repaired or replaced immediately by a Sealey qualified technician.
- √ If the cable or plug is damaged during use, switch off the electricity supply and remove from use.
- ✓ Sealey recommend that an RCD (Residual Current Device) is used with all electrical products.
- Important: Ensure that the voltage rating on the appliance suits the power supply to be used and that the plug is fitted with the correct fuse
- **DO NOT** pull or carry the appliance by the power cable.
- **DO NOT** pull the plug from the socket by the cable.

1.2. GENERAL SAFETY

- □ WARNING! Disconnect the heat gun from the mains power before changing accessories, servicing or performing other maintenance.
- Maintain the heat gun in good condition, use an authorised service agent.
- ✓ Use recommended accessories only. Unapproved accessories can be hazardous and will invalidate your warranty.
- Wear appropriate protective clothing and equipment. Work gloves and eye protection are mandatory. Protect long hair and remove loose fitting garments and jewellery. Maintain correct balance and footing and wear non-slip shoes.
- Evaluate your work area before using the heat gun. i.e. ceiling, floors and enclosures may contain flammable materials.
- √ Keep the work area clean, uncluttered and well lit. Use the heat gun only in a well ventilated area.
- ✓ Ensure that small or irregular shaped objects are secured in a vice or clamps before you work on them.
- ✓ Stay alert! Always pay attention to the work in hand when operating this heat gun.
- ✓ Guard against electric shock by not contacting grounded surfaces, i.e. pipes, radiators, etc. when using electric hand tools.
- ✓ Keep the handle dry, clean and free from oil and grease. Clean any paint or varnish from the nozzle after use.
- ✓ Allow to cool before storing (only store when cold). Store the in a safe, dry place out of the reach of children.
- DO NOT direct the hot airflow at yourself, others, animals or plants and DO NOT allow children to operate the heat gun.
- DO NOT use in rain or in a wet environment, or in areas of high humidity and damp (i.e. bathrooms, steam rooms, etc.).
- DO NOT obstruct the hot airflow by blocking or covering the air outlet.
- **DO NOT** touch the nozzle during, or after, use as it becomes extremely hot.
- DO NOT leave running unattended. Always turn off the power supply.
- **DO NOT** use for a task it is not designed for.
- **DO NOT** use in combination with chemical strippers.
- DO NOT operate when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- **▲** DANGER! DO NOT USE AS A HAIR DRYER.
- WARNING: The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood that common sense and caution are factors which cannot be built into this product, but must be applied by the operator.
- **1.3. LEAD PAINT WARNING!** Paint once contained lead as a traditional ingredient. Paint particles, resulting from the removal of such paint, are toxic and ingestion/inhalation must, therefore, be avoided. The following action must be taken before using this tool:
- 1.3.1. The operator must determine potential hazard relating to age of paint to be removed (modern paints do not have lead content).
 - **DANGER!** Keep all persons and pets away from the work area. The following are particularly vulnerable to the effects of lead paint dust: **Expectant women, babies and children.**
- 1.3.2. We recommend personal protection by using the following safety items: *Paint Spray Respirator, PE Coated Hooded Coverall Latex Gloves. Refer to Sealey Catalogue.*
- 1.3.3. Take adequate measures to contain the paint dust, flakes, and scrapings.
- 1.3.4. When task is complete continue to wear safety equipment and thoroughly clean all areas. Ensure paint waste is disposed of in sealed bags or containers.

2. INTRODUCTION

2-Step airflow control switch, with variable temperature range on both levels. Gun is designed to stand vertically, allowing use as a safe Bunsen burner alternative. Suitable for paint stripping, soft soldering, removing sticky labels and defrosting frozen pipes. Supplied with four nozzles and scraper in a storage case.

3. SPECIFICATION

Model no:	HS107K
Airflow:	250, 500L/min
Fuse Rating:	13A
Motor Power:	2000W
Power Supply Cable Length:	2m
Plug Type:	3-Pin
Supply:	230V
Temperature Range:	50-450°C/90-600°C

Temperature control Airflow speed control

4. OPERATION

4.1. PREPARING FOR USE

- 4.1.1. Before plugging into the mains ensure the switch is
- 4.1.2. in the off '0' position.
- 4.1.3. When ready to start work, set control to the required temperature
- 4.1.4. setting and air flow speed. Allow one and a half minutes to heat.
 NOTE: When new, the hot air gun may generate smoke which will decrease with use.
 - □ WARNING! KEEP HANDS AWAY FROM THE IMMEDIATE NOZZLE AREA.
 IF LEAD PAINT IS BEING REMOVED FOLLOW THE SAFETY WARNING ABOVE.
 ALWAYS WEAR GLOVES AND EYE PROTECTION.

4.2. PAINT AND VARNISH REMOVAL

- 4.2.1. The easy removal of paint and varnish requires practice. Follow these simple working techniques to achieve the required result.
 NOTE: The hot air gun is designed to remove both oil and latex based paints and varnishes from surfaces. It will not remove stains or primer coats that have impregnated the surface.
- 4.2.2. Switch the heat gun on and allow it to reach its operating temperature.
- 4.2.3. Always test on a small non-critical area first.
- 4.2.4. Hold the gun nozzle 3" (75mm) to 4" (100mm) from the paint to be removed.
- 4.2.5. After a short time the paint will soften and begin to blister.
 - DO NOT overheat the paint as this will cause it to burn which makes it more difficult to remove.
- 4.2.6. Wear eye protection, especially when stripping paint from overhead. If lead paint is being removed, refer to the warning at the beginning of this manual.
- 4.2.7. Begin scraping the paint off. Work from top to bottom. Use a scraper with smooth even strokes, warming the surface in front of the scraper by moving the hot air gun slightly from side to side.
- 4.2.8. If the correct temperature has been applied to the paint, thick, even layers can be removed in a single pass (paint should be removed in strips equal in width to the scraper blade). Scrape paint as soon as it becomes soft, as it will re-harden very quickly.
- 4.2.9. Keep the scraper blade edge clean and sharp to prevent paint peelings from building up.
- 4.2.10. After softening, shaped or profiled surfaces may be stripped by using a wire brush.
- 4.2.11. To protect surrounding surfaces from the heat, cover with a non-flammable material.

5. MAINTENANCE

- □ WARNING! Unplug from the power supply and allow to cool before performing any maintenance.
- **5.1.** Keep the air intake and outlet openings clean and free from dirt and peelings.
- 5.2. Use only a damp cloth and mild household cleaning agent to wipe the heat gun and nozzles clean. **DO NOT** use turpentine, paint thinner, gasoline or similar substances to clean the heat gun.
- **5.3.** Check the power lead and nozzles for damage before storage.
- **5.4.** Store in a safe, dry, childproof area. Allow to cool down after use.





WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk

© Jack Sealey Limited Original Language Version HS107K Issue:6 (H) 04/09/25