



# WHEELBARROW 100L HEAVY DUTY

MODEL NO: **WBR01**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear protective gloves



Wear safety footwear

## 1. SAFETY

- ✓ Always distribute the load evenly over the surface of the wheelbarrow.
- × **DO NOT** overload the wheelbarrow.
- × **DO NOT** use wheelbarrow on uneven ground and **DO NOT** run over curbs or steps - use a ramp.
- × **DO NOT** allow others to ride in the wheelbarrow.
- × **DO NOT** use the wheelbarrow if any part is damaged, paying particular attention to the wheel.
- × **DO NOT** inflate the tyre to more than 25psi.

## 2. INTRODUCTION

Heavy duty wheelbarrow ideal for construction as well as general domestic use. Our wheelbarrows use air filled pneumatic tyres, perfect for absorbing impact and are ideal for use on uneven surfaces and rough terrain. Constructed with strong tubular steel frame and rubber gripped handles. Wheel Size: Ø390mm.

## 3. SPECIFICATION

Model No.: .....WBR01  
Capacity..... 100L  
Capacity (Weight) ..... 120kg

## 4. ASSEMBLY

### 4.1. FRAME ASSEMBLY

- 4.1.1. Carefully remove plastic wrapping from the frame.
- 4.1.2. Carefully remove component package from cross member.
- 4.1.3. The front support arm is already engaged with the frame. This will need adjustment at the final stage of assembly.

### 4.2. WHEEL ASSEMBLY

- 4.2.1. Locate plastic bearing supports into recesses in wheel hub.
- 4.2.2. Undo and remove one of the bolts on the end of the metal bearing shaft.
- 4.2.3. Locate wheel within the frame brackets and slide the bearing shaft through.
- 4.2.4. Refit bolt and tighten to ensure a secure fit of wheel assembly within the frame.

### 4.3. PAN AND FRAME ASSEMBLY

- 4.3.1. Partially invert pan to allow internal access to the fixing holes.
- 4.3.2. Pass screws from inside the pan, through the frame fixing holes, and engage plain washer, spring washer and nut pack on outside.
  - × **DO NOT** tighten the fixings until all fixings are in place and engaged.

### 4.4. FRONT SUPPORT ASSEMBLY

- 4.4.1. Adjust the location of the support to enable alignment of the hole in the support to match with the fixing hole in the pan.
- 4.4.2. Pass the screw through the pan from the inside to the outside and engage plain washer, spring washer and nut pack.

### FINAL ASSEMBLY

- 4.4.3. With all fixings in place, apply final tightening to all fixings.
  - × **DO NOT** over tighten.

Parts support is available for this product. Please email [sales@sealey.co.uk](mailto:sales@sealey.co.uk) or telephone 01284 757500



#### ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

**Important:** No Liability is accepted for incorrect use of this product.

**Warranty:** Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



[sales@sealey.co.uk](mailto:sales@sealey.co.uk)



[www.sealey.co.uk](http://www.sealey.co.uk)