

2 DOOR LOCKER

MODEL NO: SL2D.V3

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.







Refer to instructions

Indoor use only Wear protective gloves

1. SAFETY

- WARNING! Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using these lockers. Wear protective gloves.
- Locate locker in a suitable work area.
- Keep the work area clean, uncluttered and ensure there is adequate lighting.
- WARNING! Use locker on level and solid ground, preferably concrete.
- Keep the locker clean and tidy in accordance with good workshop practice.
- Keep children and unauthorised persons away from the work area.
- DO NOT use the locker for any purpose other than that for which it is designed.
- DO NOT use the locker outdoors.
- DO NOT get the locker wet or use in damp or wet locations or areas where there is condensation.
- DO NOT clean the locker with any solvents which may damage the surfaces or the protective coating.




Double locker system suitable for a wide variety of commercial applications with clothes hanger bar. Doors are ventilated and fitted with cylinder lock.




Model No:	SL2D.V3
Doors:	2 door
Overall Size (W x D x H):	380 x 450 x 1850mm


ASSEMBLY


- 4.1. Lay out the back panel and the two side panels (fig.1). The side panels have a cut-out at the front (fig.2). Fit the left hand side panel to the back panel, secure using the bottom and two middle screws only.
- 4.2. Fit the right hand side panel to the back panel, using the three lower screws only to secure (fig.3).
- 4.3. Carefully stand the unit up, ensuring that the panels are not twisted.
- 4.4. Fit the door frame panel into the unit from the inside locating the frame with the side panels at the top and bottom.
- 4.5 Fit the locker top from the inside with the two holes at the back lined up with the two holes in the back panel.
- 4.6. Bend the tabs in at the front of the top, making sure that they locate into the locking holes in the door frame (figs.4 & 5).

















- 4.7. Place the bottom shelf into the locker with the two cut outs facing towards the door (fig.6), push it down into place.
- 4.8. Carefully tip locker over backwards and lower to the floor. Secure the bottom shelf to the back panel using two screws (fig.7). Stand locker up.







- 4.9. All shelves are the same design as the bottom shelf with two cut-outs that face towards the door. Locate each one and push down into place. If required, drill holes and fix shelves in position with a retaining screw (fig.8).
- 4.10. Place hanging bars in position (fig.9).





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

© Jack Sealey Limited Original Language Version SL2D.V3 Issue 2 (4) 19/06/23