




3-Gang Socket Adaptor

13A 240V



GB

Specification

Max. voltage: 250V~, 50Hz

Max. power: 13A

Plug: Earthed British mains plug (BS1363), 13A fuse

Sockets: 3 earthed British sockets (BS1363)

Ingress Protection: IP20



As part of our ongoing product development, specifications of Powermaster products may alter without notice.

General Safety Warnings

Carefully read and understand these instructions, information on the packaging and any label attached to the tool before use. Keep these instructions with the product for future reference. Ensure all persons who use this product are fully acquainted with these instructions.

- ALWAYS apply general precautionary measures for handling electricity and electrical devices
- The combined power of all connected devices MUST NOT exceed 13A
- NEVER connect multiple extension leads together to extend the reach of a device. Use a single, longer extension lead instead
- This extension lead must NEVER come into contact with water. INDOOR USE ONLY. DO NOT use in wet or damp locations
- Position extension leads carefully and ensure they do not become a tripping hazard

Operating Instructions

1. Insert 3-Way Adaptor into an earthed UK socket
2. Connect devices to the sockets
3. Switch on the power to the socket to start powering the devices attached
4. Switch off and remove all devices plugged in, before disconnecting the adaptor from the mains power supply

Maintenance

- Before every use, check the power cable, plug and plastic housing for damage and excessive use. This device is non-rewirable. DO NOT use and discard if any damage is detected
- Keep your extension lead dry and clean at all times. Clean with a soft brush, or dry cloth
- The UK mains plug has an internal 13A fuse. If there is no power to any of the four sockets, this fuse may have blown. Replace with an identical 13A fuse ONLY.

Storage

- Store this tool carefully in a secure, dry place out of the reach of children

Disposal

Always adhere to national regulations when disposing of power tools that are no longer functional and are not viable for repair.

- Do not dispose of power tools, or other waste electrical and electronic equipment (WEEE), with household waste
- Contact your local waste disposal authority for information on the correct way to dispose of power tool