

# 12V SV12 SERIES CORDLESS COMBI DRILL Ø10MM - BODY ONLY

MODEL NO: CP1201

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to

instruction

manual









Wear eye Wear protective protection gloves

Wear ear protection

Wear a mask

### 1. SAFETY

#### 1.1. GENERAL SAFETY

- ✓ Maintain the drill and battery in good condition. Check moving parts alignment on a regular basis.
- Replace or repair damaged parts. Use an authorised service agent and recommended parts only. Unauthorised parts may be
  dangerous and will invalidate the warranty.
- Ensure the drill is switched off before installing the battery pack.
- Keep the drill and charger clean for best and safest performance.
- Remove ill fitting clothing. Remove ties, watches, rings and other loose jewellery and contain long hair.
- Evaluate your working area before using the drill; e.g. ceilings, floors and enclosures may contain electrical items or water piping
- Ensure battery pack is correctly inserted into the drill handle and latched in place before attempting to switch on drill.
- ✓ Secure loose work pieces with a clamp, vice or other adequate holding device.
- Avoid unintentional starting.
- ✓ Wear approved safety eye protection (standard spectacles are not adequate).
- Maintain correct balance and footing. Ensure the floor is not slippery and wear non-skid shoes.
- ✓ Be aware that this drill does not need to be plugged into the mains power.
- Keep chuck direction switch in the locked position until the drill is required for use.
- ✓ Keep children and unauthorised persons away from the working area.
- DO NOT use the drill where there are flammable liquids, solids or gases, such as paint solvents, etc.
- **DO NOT** allow children to operate the drill.
- DO NOT operate the drill if any parts are missing as this may cause failure and/or personal injury.
- **DO NOT** hold unsecured work piece in your hand.
- **DO NOT** leave the drill operating unattended.
- DO NOT carry the drill with your finger on the power switch. Keep chuck direction switch in the locked position.
- **DO NOT** use the drill for a task it is not designed to perform.
- DO NOT operate the drill when you are tired or under the influence of alcohol, drugs or intoxicating medication.
- **DO NOT** get the drill or battery charger wet or use in damp or wet locations.

### 1.2. HAND ARM VIBRATION

### WARNING! – Risk of Hand Arm Vibration Injury.

This tool may cause Hand Arm Vibration Syndrome if its use is not managed adequately.

This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC.

This tool is to be operated in accordance with these instructions.

Measured vibration emission value (a): 9.6m/s<sup>2</sup>

### Uncertainty value (k): 1.5 m/s<sup>2</sup>

Please note that the application of the tool to a sole specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emission is conducted prior to commencing with a specialist task.

A health and safety assessment by the user or employer will need to be carried out to determine the suitable duration of use for each tool. **NB:** Stated Vibration Emission values are type-test values and are intended to be typical.

Whilst in use, the actual value will vary considerably from and depend on many factors, such as the operator, the task and the inserted tool or consumable

NB: ensure that the length of leader hoses is sufficient to allow unrestricted use, as this also helps to reduce vibration.

The state of maintenance of the tool itself is also an important factor, a poorly maintained tool will also increase the risk of Hand Arm Vibration Syndrome.

## 1.3. HEALTH SURVEILLANCE

We recommend a programme of health surveillance to detect early symptoms of vibration injury so that management procedures can be modified accordingly.

# 1.4. PERSONAL PROTECTIVE EQUIPMENT

We are not aware of any personal protective equipment (PPE) that provides protection against vibration injury that may result from the uncontrolled use of this tool. We recommend a sufficient supply of clothing (including gloves) to enable the operator to remain warm and dry and maintain good blood circulation in fingers etc. Please note that the most effective protection is prevention, please refer to the Correct Use and Maintenance section in these instructions. Guidance relating to the management of hand arm vibration can be found on the HSC website www.hse.gov.uk - Hand-Arm Vibration at Work.

### 2. INTRODUCTION

Compact, lightweight cordless drill/driver with added hammer function. Comfortable composite housing with soft grip to reduce vibration. Ø0.8-10mm Keyless chuck. 2-Speed settings and 21 torque settings provide the control required to complete various tasks. All metal gear construction for ultimate durability and performance. Integral LED battery level indicator and LED worklight. Supplied with belt hook for safer storage while not in use. Requires Model No. CP1200BP 12V 1.5Ah Lithium-ion Battery and Model No. CP1200MC Battery Charger.

### 3. SPECIFICATION

	<b>CP1201</b> ed):12V 1.5Ah Lithium-ion
	12V 3Ah Lithium-ion
	12V 4Ah Lithium-ion
Chuck Size:	Ø10mm
Drilling Capacities:	Wood - Ø20mm
	Metal - Ø10mm
	Concrete - Ø10mm
Impact Rate:	0-6000/0-19500bpm
	25Nm
	80/69dB(A)
No-Load Speed:	0-400/0-1300rpm
	CP1200MC - Mains Charger
Vibration/Uncertainty:	9.6/1.5m/s²



### 4. OPERATION

#### 4.1. USING THE DRILL

- 4.1.1. Ensure the direction selector (fig.1) is in the mid (lock) position.
- 4.1.2. Open the chuck by turning the rear chuck collar.
- 4.1.3. Insert the required drill or screwdriver bit into the chuck fully and tighten.
- 4.1.4. The speed range of the drill is controlled by the speed selector on top of the casing (high for drilling, low for screwdriving)
- 4.1.5. Select clockwise or anticlockwise direction by means of the direction selector.
- 4.1.6. Select the required screwdriver / Drill / Hammer setting by turning the Hammer selector ring.
- 4.1.7. Select the required screwdriver torque by turning the torque selector ring. The torque increases from 1-21.
- 4.1.8. Squeeze the trigger to start the drill; initial pressure switches on the LED worklight, further pressure starts the motor and increases speed.



#### **WEEE REGULATIONS**

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



**Note**: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR

01284 757500 Representation of the sealey of the sealey